
SONY

DIGITAL MULTI EFFECTS DME-3000 DME CONTROL PANEL BKDM-3010



BKDM-3020 BKDM-3021 BKDM-3022 BKDM-3023 BKDM-3030 BKDM-3040 BKDM-3050 BKDM-3060

INSTALLATION MANUAL 1st Edition (Revised 2)

For the customers in the USA

WARNING

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

The shielded interface cable recommended in this manual must be used with this equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:

Using this unit at a voltage other than 120V may require the use of a different line cord or attachment plug, or both. To reduce the risk of fire or electric shock, refer servicing to qualified service personnel.

For customers in Canada

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Pour les utilisateurs au Canada

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

For the customers in Europe

WARNING

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Pour les utilisateurs en Europe

AVERTISSEMENT

Il s'agit d'un produit de Classe A. Dans un environnement domestique, cet appareil peut provoquer des interférences radio, dans ce cas l'utilisateur peut être amené à prendre des mesures appropriées.

Für Kunden in Europa

Warnung

Dies ist eine Einrichtung, welche die Funk-Entstörung nach Klasse A besitzt. Diese Einrichtung kann im Wohnbereich Funkstörungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen durchzuführen und dafür aufzukommen.

Für Kunden in Deutschland

Dieses Produkt kann im kommerziellen und in begrenztem Maße auch im industriellen Bereich eingesetzt werden.

VORSICHT

Um Feuergefahr und die Gefahr eines elektrischen Schlages zu vermeiden, darf das Gerät weder Regen noch Feuchtigkeit ausgesetzt werden.

Um einen elektrischen Schlag zu vermeiden, darf das Gehäuse nicht geöffnet werden. Überlassen Sie Wartungsarbeiten stets nur einem Fachmann.

DME-3000	Serial No. 10001 and Higher
BKDM-3010	Serial No. 10001 and Higher
BKDM-3020	Serial No. 10001 and Higher
BKDM-3021	Serial No. 10001 and Higher
BKDM-3022	Serial No. 10001 and Higher
BKDM-3023	Serial No. 10001 and Higher
BKDM-3030	Serial No. 10001 and Higher
BKDM-3040	Serial No. 10001 and Higher
BKDM-3050	Serial No. 10001 and Higher
BKDM-3060	Serial No. 10001 and Higher

目 次 **TABLE OF CONTENTS**

1. 取り扱	い操作	1. OPERATION
1-1 概要	······ 1-1(J)	1-1 Overview1-1(E)
1-1-1	主な特長1-1(J)	1-1-1 Principal Features1-1(E)
	別売り品1-3(J)	1-1-2 Optional Accessories
1-1-2		1-1-3 Peripherals Configuration 1-4(E) 1-1-4 Functions Provided by
1-1-3	周辺機器の構成 ······1-5(J)	Option Boards1-5(E)
1-1-4	オプション基板を組み込んだときに	1-1-5 Option Board Precautions
	使用できる機能1-6(J)	1-2 Location and Function of Parts1-7(E)
1-1-5	使用上のご注意1-7(J)	1-2-1 Front Panel and Interior1-7(E)
	の名称と働き ···············1-8(J)	1-2-2 Rear Panel1-10(E)
		1-2-3 BKDM-3010 Control Panel (Option)
1-2-1	前面パネルと内部1-8(J)	Rear Panel 1-12(E)
1-2-2	後面パネル ······1-11(J)	1-3 System Configuration Examples1-13(E)
1-2-3	コントロールパネルBKDM-3010	1-3-1 Control Panel and I/O
	(別売り)後面1-13(J)	Connections
40 5.7	テム構成例 ····································	1-3-2 DVS-2000C Digital Video Switcher Connections I-14(E)
		1-3-3 DVS-6000/6000C Digital Video
1-3-1	コントロールパネルおよび入出力機器	Switcher Connections 1-15(E)
	との接続1-14切	1-3-4 DVS-8000/8000C Digital Video
1-3-2	デジタルビデオスイッチャーDVS-2000C	Switcher and DME-5000 Digital
•	との接続 ······1-15(J)	Multi Effects Connections1-16(E)
1-3-3	デジタルビデオスイッチャーDVS-6000	1-3-5 BVE-2000 Editing Control System
1-3-3	/6000Cとの接続1-16(J)	Connections1-17(E)
		1-3-6 DVS-V1201 Digital Video Routing
1-3-4	デジタルビデオスイッチャーDVS-8000	Switcher Connections1-17(E) 1-4 Specifications1-18(E)
	/8000Cおよびデジタルマルチエフェクト	1-4-1 DME-30001-18(E)
	DME-5000との接続 ······1-17(J)	1-4-2 BKDM-30101-22(E)
1-3-5	エディティングコントロールシステム	1-4-3 BKDM-30201-22(E)
1-0-0	BVE-2000との接続 ················1-18(J)	1-4-4 BKDM-30211-23(E)
		1-4-5 BKDM-30221-23(E)
1-3-6	デジタルビデオルーティングスイッチャー	1-4-6 BKDM-30231-24(E)
	DVS-V1201との接続1-18(J)・	1-4-7 BKDM-30301-24(E)
1-4 仕様	ŧ ······1-19(J)	1-4-8 BKDM-30401-25(E)
1-4-1	DME-3000 ·····1-19(J)	1-4-9 BKDM-30501-25(E) 1-4-10 BKDM-30601-26(E)
1-4-2	BKDM-3010 ·····1-24(J)	1-4-10 BKD141-30001-20(E)
1-4-3	BKDM-3020 ·····1-24(J)	
1-4-4	BKDM-3021 ·····1-25(J)	
1-4-5	BKDM-3022 ·····1-25(J)	
1-4-6	BKDM-3023 ······1-26(J)	
1-4-7	BKDM-3030 ·····1-27(J)	
1-4-8	BKDM-3040 ······1-27(J)	
1-4-9	BKDM-3050 ······1-27(J)	
	BKDM-3060 ·····1-28(J)	

2. 設置

2-1. 使用環境	2-1(J)
2-2. 一次側電源電圧	2-1(J)
2-3. 外形寸法	
2-4. 設置スペース	2-3(J)
2-5. トラックボールの取付け	2-4(J)
2-6. 設置時の確認および設定	2-5(J)
2-6-1. 基板内スイッチの設定および	
LEDの説明	
2-6-2. カード基板の設置方法	2-7(J)
2-6-3. オプション基板の取付け	
2-6-4. 二次側電源電圧の確認	2-9(J)
2-6-5. マルチチャンネル時の設定	
2-6-6. コンバイナー基板設置時の設定	2-12(J)
2-7. 接続コネクタ	
2-8. コネクタの入出力信号	2-14(J)
2-8-1. DME-3000	2-14(J)
2-8-2. BKDM-3010	2-16(J)
2-9. 付属アクセサリ	
2-9-1. 付属電源コードの接続	2-17(J)
2-10. 別売アクセサリ	2-18(J)
2-11. ラックマウント	
2-12. ソフトウェアのインストール方法	
2-12-1. BKDM-3010	2-21(J)
2-12-2. DME-3000	
2-13. システム接続時のスイッチ設定	2-23(J)
2-13-1. デジタルビデオスイッチャーとの	
接続	2-23(J)
2-13-2. BKDM-5080との接続	
2-13-3. DVS-V1201/BVS-V1201との接続.	2-24(J)

2. INSTALLATION

2-1. Operating Environment	.2-1(E)
2-2. Primary Supply Voltage	
2-3. External Dimensions	
2-4. Installation Space	
2-5. Track Ball Installation	
2-6. Confirmation and Setting During	` '
Installation	.2-5(E)
2-6-1. Switch Setting on Board and	•
LED Description	.2-5(E)
2-6-2. Card Boards Installation	
2-6-3. Optional Board Installation	
2-6-4. Secondary Supply Voltage	` '
Confirmation	.2-9(E)
2-6-5. Multi Channel Setting	
2-6-6. Setting during Combiner Board	
Installation	
2-7. Connectors	.2-13(E)
2-8. Connector Input/Output Signals	.2-14(E)
2-8-1. DME-3000	.2-14(E)
2-8-2. BKDM-3010	.2-16(E)
2-9. Supplied Accessories	.2-17(E)
2-9-1. Connection of Supplied Power	
Cord	.2-17(E)
2-10. Optional Accessories	
2-11. Rack Mounting	
2-12. Software Installation	
2-12-1. BKDM-3010	.2-21(E)
2-12-2. DME-3000	.2-22(E)
2-13. Switch Setting During Connecting	
Other Unit	.2-23(E)
2-13-1. Connection for Digital Video	
Switcher	
2-13-2. Connection for BKDM-5080	.2-23(E)
2-13-3. Connection for DVS-V1201/	
BVS-V1201	.2-24(E)

デジタルマルチエフェクトDME-3000のマニュアルについて

デジタルマルチエフェクトDME-3000と、これを制御するためのコントロールパネルBKDM-3010を操作するには、それぞれ下記のマニュアルが必要です。

DME-3000インストレーションマニュアル

(このマニュアルです。デジタルマルチエフェクトに付属しています。) 第1章「取り扱い操作」では、DME-3000および別売り品の概要、各部の働き、接続 例などを記載しています。デジタルマルチエフェクトを管理される方は、この章 を最初にお読みください。

第2章以降では、システムの設置に必要な情報を記載しています。

DME-3000メンテナンスマニュアル Part 1

(デジタルマルチエフェクトに付属しています。) デジタルマルチエフェクトシステムの保守点検に必要な情報を記載しています。 システムのメンテナンスが必要になったときや、何らかの異常が発生したときに お読みください。

DME-3000メンテナンスマニュアル Part 2

(別売り)

デジタルマルチエフェクトシステムのハードウェアに関する情報を記載しています。

BZDM-3010ユーザーガイド

(別売りのソフトウェアに付属しています。)

コントロールパネルの各部の働きと、デジタルマルチエフェクトの操作方法を記載しています。デジタルマルチエフェクトを操作するときにご覧ください。

第1章 取り扱い操作

1-1 概要

デジタルマルチエフェクトDME-3000は、デジタルビデオスイッチャーなどから 入力された映像をデジタル処理することにより、画質を損なわずに高度な効果を 生み出すことのできるデジタル映像効果装置です。

本機の操作は、別売りの専用コントロールパネルBKDM-3010から行います。

1-1-1 主な特長

シリアル方式によるデジタル入出力

デジタル信号の入出力はすべてシリアルで行っており、BNCケーブル1本でデジタルビデオ信号を伝送することができます。これによって、従来のパラレル伝送に比べて接続が容易になるだけでなく、長距離伝送も可能になります。

10ビット処理

本機は、アナログ/デジタルいずれの信号も10ビットの精度で入出力し、内部では10~12ビットの精度で処理します。したがって、画質の劣化は最小限に抑えられます。

コンポジット/コンポーネントの両方式に対応

本機では、入出力用のオプション基板を4種類(BKDM-3020/3021/3022/3023)の中から選ぶことができます。コンポーネントとコンポジットのそれぞれの方式について、デジタルのみの基板とデジタル/アナログの両方に対応する基板の2種類が用意されているので、接続するスイッチャーに合った基板を組み込むことにより、既存のシステムにも柔軟に対応できます。また、コンポーネント方式を使用時の525/625の切り換えは、メニュー操作によって容易に行えます。

16:9コンポーネント信号に対応

4:3コンポーネント信号処理から、サンプリング周波数13.5MHzの16:9コンポーネントワイドスクリーンに対応した信号処理への切り換えは、メニュー操作で容易に行うことができます。入出力用のオプション基板は、両方の信号処理方式に対応しています。



デジタルビデオスイッチャーDVSシリーズとのリンクオペレーション

DVSシリーズのスイッチャーとの接続により、次の機能が使えるようになります。

 \bullet DVS-2000C : DME WIPE $^{\circledR}$

• DVS-6000/6000C : KEY FRAME LINK®

• DVS-8000/8000C:KEY FRAME LINK®、DME-3000の制御 これらのスイッチャーと本機はデジタル機器同士で接続されるため、高画質を維持したまま、相互に画像処理を行うことができます。ただし、DVS-8000/8000C のコントロールパネルBKDS-8010からDME-3000を制御する場合は、一部の機能が制約を受けます。

複数チャンネルの同時オペレーションが可能

本機に他のDME-3000を接続することにより、2台のDME-3000を2つのチャンネルとして、同じコントロールパネルから操作することができるようになります。この場合、1つのチャンネルだけを操作することも、2つのチャンネルを同時に操作することもできます。また、本機の上位機種であるDME-5000と混在させたオペレーションも可能です。

コンバイナー機能による画像の結合

2台のDME-3000にオプション基板(BKDM-3050)を組み込んでシリアルに接続することにより、同一画面上で2つの画像をコンバイン(結合)することができます。この操作には、平面だけでなく、奥行きに関する情報も含む、コンバイン用の特殊な信号を使用します。さらに、コンバインされた画像をグローバル軸に沿って回転させるなど、高度な3次元エフェクトを付加することもできます。本機の上位機種であるDME-5000とのコンバイン操作も可能です。

フレーム/フィールド処理の自動切り換え

本機では、画像の動きに応じて、フレーム単位またはフィールド単位で画像処理を行います。フレーム単位の処理では、フィールド2枚分の情報量をもとに画像を処理するため、画質の劣化を抑えることができます。エフェクトによって新しい画像を作り出す場合は、フレーム単位の処理のほうが精度が高くなります。また、動きのある画像を処理する場合は、フィールド単位の処理によって自然な動きを得ることができます。これらの処理方法は、動き検出機能によって自動的に切り換えられます。

BKDM-3010 DME CONTROL PANEL (DMEコントロールパネル)

DME-3000を制御するためのコントロールパネルです。

BKDM-3020 COMPOSITE DIGITAL INPUT/OUTPUT BOARD (コンポジットデジタルインプット/アウトプットボード)

DME-3000でD2シリアルデジタル信号を入出力するための基板です。

BKDM-3021 COMPONENT DIGITAL INPUT/OUTPUT BOARD (コンポーネント デジタルインプット/アウトプットボード)

DME-3000でD1シリアルデジタル信号を入出力するための基板です。

BKDM-3022 COMPOSITE DIGITAL/ANALOG INPUT/OUTPUT BOARD (コンポジットデジタル/アナログ インプット/アウトプットボード)

DME-3000でD2シリアルデジタル信号とアナログNTSC信号を入出力するための基板です。

BKDM-3023 COMPONENT DIGITAL/ANALOG INPUT/OUTPUT BOARD (コンポーネントデジタル/アナログ インプット/アウトプットボード) DME-3000でD1シリアルデジタル信号とアナログコンポーネント信号を入出力するための基板です。

BKDM-3030 NON-LINEAR EFFECTS BOARD(ノンリニアエフェクトボード) DME-3000でノンリニアエフェクトを発生させる基板です。

BKDM-3040 WIPE/GRAPHICS BOARD (ワイプ/グラフィックスボード)
DME-3000でワイプクロップ、モディファイマスク、カラーミックスを行った

り、3Dトランスフォームの回転軸表示、画枠表示を可能にするための基板です。 BKDM-3050 COMBINER/LIGHTING BOARD(コンバイナー/ライティングボー

ド) 奥行き情報を付加して、2台のDME-3000の映像を合成したり、DME-3000の出力 映像に光が当たったような効果を加えるための基板です。



BKDM-3060 KEY CHANNEL/RECURSIVE EFFECTS BOARD (キーチャンネル /リカーシブエフェクトボード)


DME-3000で外部キーを扱えるようにし、さらにビデオ、キーに残像効果を付加するための基板です。

BZDM-3010 OPERATION SOFTWARE WITH MANUAL (ソフトウェアと付属マニュアル)

DME-3000とBKDM-3010を操作するためのソフトウェアと、コントロールパネルの操作方法を記載したユーザーガイドです。

1-1-3 周辺機器の構成

本機を中心とした周辺機器の構成は以下のとおりです。点線の枠内は本機を使用 するために必要最小限の構成です。



DME-3000の周辺機器の構成



1-1-4 オプション基板を組み込んだときに使用できる機能

本機に組み込むオプション基板の組み合わせによって使用できるようになる機能 は次のとおりです。ここでいう基本システムとは、前ページの図の点線の枠で囲 まれた部分です。

表の見かた

「○」の意味:機能の行で「○」が付いている列のオブション基板を単独で装着すれば、その機能が使用できるようになります。

「◎」の意味:機能の行で「◎」が付いている列のオプション基板を組み合わせたときにのみ、その機能が使用できるようになります。例えば、「外部キー信号を使ったページターン機能」は、BKDM-3030/3050/3060の3つがそろったときに初めて使用できるようになります。

オプション基板を組み込んだときに使用できる機能

	•		ことの 次州 じゅう 放北			
		基本システム (DME-3000+BKDM- 3010+BKDM-302X)	オプション基板			
			BKDM-3030	BKDM-3040	BKDM-3050	BKDM-3060
	10ビット4:2:2:4信号処理	0				
	外部キー					0
	フレーム単位の補間	. 0				
	3Dリニアトランスフォーム	0				
	ビデオモディファイ	0				
	インプットフリーズ	0				
デ	ボーダー、クロップ	0				
ジ	マルチムーブ	0				
夕	ノンリニアエフェクト		0			
ル	スプリット/ミラー		0			
マ	ドロップシャドウ(3Dリニア)	0				
ル	ドロップシャドウ(ノンオーバーラップノンリニア)		0			
7	ドロップシャドウ(オーバーラップノンリニア ⁿ⁾		0			0
I	ビデオデフォーカス、ブルア	0				
7	キーデフォーカス、ブルア					0
I	リカーシブエフェクト					0
2	ディム/フェード				0	
, ,	コンバイン				0	
機	オーバーラップノンリニアのエッジの画質向上		0		0	
能	外部キー信号を使ったページターン		0		0	0
BE	ライティング(バー、フラット)				0	
	ライティング(バー、フラット、サークル)		0		0	
	ワイブパターンによるスポットライティング			0		
	ワイプクロップ、モディファイマスク			0		0
	カラーミックス			0		
	グラフィックス			0		0

¹⁾ オーバーラップノンリニアとは、画像の重なり部分が生じるノンリニアエフェクトのことです。DME-3000では、スフィア、シリンダー、ページターン、ロールの機能がこれに該当します。ノンオーバーラップノンリニアとは、それ以外のノンリニアエフェクトのことです。

1-1-5 使用上のご注意

プリント基板の抜き差しについて

通常はプリント基板を抜き差しすることは避けてください。 保守点検や別売り基板の取り付けなどのため、やむを得ず抜き差しするときは、 以下のことを必ず守ってください。


- 基板を抜き差しする前に、必ず本機のPOWERスイッチをOFFにしてください。
 - ◆POWERスイッチの位置については、1-8(J)ページをご覧ください。
- 基板を差し込んだ後、電源を入れる前に、本機内部に表示されているスロット 番号と基板に表示されているスロット番号が一致していることを確認してくだ さい。

ご注意

上記の注意が守られなかった場合は、回路が故障することがあります。



CPU-114基板とBKDM-3020~3023基板には、本機の動作状態を表すインジケーターや、調整、テストのための部品がキャビネット前面側に装備されています



内部基板のスイッチ、インジケーター、端子

1 +5V(A)チェック端子

+5V(A)電源電圧をチェックするためのブローブ挿入端子です。

②CPU RUN(CPU動作)インジケーター

CPUの動作状態に対応した数字が表示されます

③RESET(リセット)スイッチ

CPUをリセットします。

4割り込みスイッチ

ONにすると、RS-232Cボートに入力される通信データを受け付けるための割り込み処理を実行します 通常は触れないでください。

1-10 (J) | 第1章 取り扱い操作

⑤RS-232Cポート


通信用のポートです。通常は何も接続しないでください。

6 治具接続端子

メンテナンス用の端子です。通常は何も接続しないでくだ さい。

+5V(B)、-5V電源電圧をチェックするためのプローブ挿 人端子です。

1-2-2 後面パネル



後面パネル

①COMBINER INPUTS (コンバイナー入力) 端子 (BNC型)

本機の画像と他のDME-3000の画像をコンバインするとき、コンバイン用のシリアルデジタル信号を入力します。コンバインされた画像は、本機のDIGITAL OUTPUTS端子

②およびANALOGOUTPUTS端子

③から出力されます。コンポーネントフォーマットではVIDEO/Y、KEY/Z、Zの各端子を、コンポジットフォーマットではVIDEO/Y、EXT/C、KEY/Z、Zの各端子を使用します。コンポーネントフォーマット使用時にEXT/C端子から入力されたシリアルデジタル信号は、バックグラウンドやボーダーとして使用することができます。これらの端子を使用するためには、本機にオプション基板BKDM-3050を組み込む必要があります。

②COMBINER OUTPUTS (コンパイナー出力)端子 (BNC

本機の画像と他のDME-3000の画像をコンバインするとき、コンバイン用のシリアルデジタル信号を出力します。コンポーネントフォーマットではVIDEO/Y、KEY/Z、Zの各端子を、コンポジットフォーマットではVIDEO/Y、EXT/C、KEY/Z、Zの各端子を使用します。これらの端子を使用するためには、本機にオプション基板BKDM-3050を組み込む必要があります。

③ ANALOG INPUTS(アナログ信号入力)端子(BNC型)

アナログのビデオ信号およびキー信号を入力します。これらの端子に入力される信号とREFINPUT端子⑥に入力される基準ビデオ信号との位相差が一0.3H~+1.8H以内であれば、自動的に位相調整が行われます。ただし、自動位相調整機能を働かせるためには、コントロールパネルBKDM-3010のIN/OUTメニューで「TBC CENTER」(TBCウィンドウのセンター位置)の値を4つの中から選んでおく必要があります。これらの端子を使用するためには、本機にオプション基板BKDM-3022またはBKDM-3023を組み込む必要があります。

④ DIGITAL OUTPUTS (デジタル信号出力)端子 (BNC型)

シリアルデジタルのビデオ信号およびキー信号を出力します。1、2の2系統から同じ信号が出力されます。これらの端子を使用するためには、本機にオプション基板BKDM-3020、BKDM-3021、BKDM-3022、BKDM-3023のいずれかを組み込む必要があります。

⑤ ANALOG OUTPUTS (アナログ信号出力) 端子 (BNC

型)

アナログのビデオ信号およびキー信号を出力します。1、2 の2系統から同じ信号が出力されます。これらの端子を使 用するためには、本機にオプション基板BKDM-3022また はBKDM-3023を組み込む必要があります。

@REF INPUT(基準ビデオ信号入力)端子(BNC型)

アナログの基準ビデオ信号を入力します。2つの端子は ループスルーになっており、どちらかの端子に入力した信 号を、そのままもう一方の端子から出力することができま す。ループスルー出力を使用しないときは、空いているほ うの端子を必ず付属の75Ω終端器で終端してください。

⑦SPARE(予備)端子(BNC型)

予備の端子です。通常は使用しません。

③DIGITAL INPUTS(デジタル信号入力端子)(BNC型)

シリアルデジタルのビデオ信号およびキー信号を入力します。これらの端子に入力される信号とREFINPUT端子 でに入力される基準ビデオ信号との位相差が一0.3H~+1.8H以内であれば、自動的に位相調整が行われます。ただし、自動位相調整機能を働かせるためには、コントロールパネルBKDM-3010のIN/OUTメニューで「TBC CENTER」(TBCウィンドウのセンター位置)の値を4つの中から選んでおく必要があります。これらの端子を使用するためには、本機にオプション基板BKDM-3020、BKDM-3021、BKDM-3022、BKDM-3023のいずれかを組み込む必要があります。

⑨CONTROL PANEL(コントロールパネル)端子(D-sub 9ピン、D-sub 25ピン)

2つのD-sub 25ピン端子のどちらかに、別売りのコントロールパネルBKDM-3010を接続します。4つの端子はループスルーになっており、空いているD-sub 25ピン端子に他のDME-3000を接続すると、同じコントロールパネルから2台のDME-3000を操作できるようになります。これらの端子はRS-422A規格に準拠しています。D-sub 25ピン端子を経由して、本機からコントロールパネルBKDM-3010に+12V電源と基準ビデオ信号が供給されます。D-sub 9ピン端子は現在は使用しません。

外部のマトリックススイッチャーに接続すると、本機への 入力信号をマトリックススイッチャーで切り換えることが できるようになります。2つの端子のうち、どちらか一方 だけを使用してください。

①EDITOR(エディター)端子(D-sub 9ピン)

エディティングコントロールシステムBVE-2000などの外部機器に接続すると、その外部機器から本機を制御できるようになります。この端子はRS-422A規格に準拠しています。

12GPI (汎用入出力) 端子 (D-sub 15ピン)

外部機器に接続し、トリガー信号を入力します。4系統が 用意されており、コントロールパネルBKDM-3010のメ ニュー操作によって、個々の系統に対して入力条件を設定 することができます。

®AC IN (AC電源入力)端子

付属の電源コードでAC電源に接続します。

12アース端子


システムの接地線に接続します。

⑤SWITCHER PANEL(スイッチャーパネル)端子(D-sub 9ピン)

デジタルビデオスイッチャーDVS-6000のコントロールパネルBKDS-6010に接続すると、スイッチャーコントロールパネルからキーフレームのラン、リコールなどを実行できるようになります。デジタルビデオスイッチャーDVS-8000/8000CのコントロールパネルBKDS-8010に接続すると、スイッチャーコントロールパネルからDME-3000を制御できるようになります。ただし、この場合は、機能の一部に制約が生じます。

2つの端子はループスルーになっており、空いているほうの端子に他のDME-3000を接続すると、同じ外部機器から2台のDME-3000を操作できるようになります。

1-2-3 コントロールパネルBKDM-3010(別売り)後面



コントロールパネルBKDM-3010後面

①PROCESSOR(プロセッサー)端子(D-sub 25ピン)

DME-3000に接続します。この端子を経由してDME-3000か らコントロールパネルへ+12V電源、基準ビデオ信号、RS-422インターフェース信号が供給されます。

②MONITOR (モニター)端子(D-sub 15ピン、ハイデンシティー)

CPD-15SF7 などのモニターディスプレイを接続します。


3RS-232C端子(D-sub 9ピン)

汎用RS-232Cインターフェースのマウス (PCY-330) を接続することができます。



1-3 システム構成例


1-3-1 コントロールパネルおよび入出力機器との接続



コントロールパネルおよび入出力機器との接続

1-3-2 デジタルビデオスイッチャーDVS-2000Cとの接続


別売り基板BKDM-3050を装着していないときは、DME-3000のDIGITAL OUTPUTS KEY端子からKEY信号を出力してください。



デジタルビデオスイッチャーDVS-2000Cとの接続




1-3-3 デジタルビデオスイッチャーDVS-6000/6000Cとの接続



デジタルビデオスイッチャーDVS-6000/6000Cとの接続


1-3-4 デジタルビデオスイッチャーDVS-8000/8000CおよびデジタルマルチエフェクトDME-5000との接続



DVS-8000/8000CおよびDME-5000との接続




1-3-5 エディティングコントロールシステムBVE-2000との接続



エディティングコントロールユニットBVE-2000との接続

1-3-6 デジタルビデオルーティングスイッチャーDVS-V1201との接続



デジタルビデオルーティングスイッチャーDVS-V1201との接続

1-4 仕様

1-4-1 デジタルマルチエフェクトDME-3000

一般

電源

AC90~264V

消費電力

約400W(全オプション基板装着時)

電源力率

90%以上

使用温度

-20~+55℃(保存温度)

5~40℃(動作保証)

10~35℃(性能保証)

相対湿度

80%以下(動作保証)

70%以下(性能保証)

外形寸法

424×221.2×450mm (幅×高さ×奥行き) (突

起物を除く)

重量

25kg(全オプション基板装着時)

入出力コネクター

DIGITAL INPUTS

コンポーネント

VIDEO:シリアルデジタル信号入力

BNC型(×2)、75Ω

KEY:シリアルデジタル信号入力

BNC型(×2)、75Ω

コンポジット

VIDEO:シリアルデジタル信号入力

BNC型(×2)、75Ω

KEY:シリアルデジタル信号入力

BNC型($\times 2$)、75Ω

DIGITAL OUTPUTS

コンポーネント

VIDEO:シリアルデジタル信号出力

BNC型(×2)、75Ω

KEY:シリアルデジタル信号出力

BNC型(×2)、75Ω

コンポジット

VIDEO:シリアルデジタル信号出力

BNC型(×2)、75Ω

KEY:シリアルデジタル信号出力

BNC型(×2)、75Ω

ANALOG INPUTS

コンポーネント

Y、R-Y、B-Y:アナログコンポーネント

信号入力、BNC型(×6)

Y:1Vp-p、SYNC付き

R-Y, B-Y: 0.7Vp-p

KEY: VS、1Vp-p、BNC型(×2)

コンポジット

VIDEO:アナログコンポジット信号入力

BNC型(×2)

KEY:VS、1Vp-p、BNC型(×2)

ANALOG OUTPUTS コンポーネント

Y、R-Y、B-Y(色差信号出力時):アナロ

グコンポーネント信号出力、BNC型(×6)

Y:1Vp-p、SYNC付き

R-Y, B-Y: 0.7Vp-p

R、G、B、SYNC(RGB信号出力時):アナ

ログRGB信号出力、BNC型(×8)

R、G、B: 0.7Vp-p

SYNC: 2.35Vp-p

KEY: VS、1Vp-p、BNC型(×2)

コンポジット

VIDEO:アナログコンポジット信号出力

BNC型(×2)

KEY:VS、1Vp-p、BNC型(×2)

REFINPUT

コンポーネント

アナログリファレンス信号入力

BNC型(×2)、ブラックバーストまたは コンポジットシンク、0.3~2Vp-p、ルー

プスルー

コンポジット

アナログリファレンス信号入力

BNC型(×2)、ブラックバースト、ルー

プスルー

COMBINER INPUTS

コンポーネント: VIDEO、KEY、Z シリア

ルデジタル信号入力、BNC型(×3)

コンポジット:Y、C、KEY、Z シリアルデ

ジタル信号入力、BNC型(×4)

COMBINER OUTPUTS

コンポーネント: VIDEO、KEY、Z シリア

ルデジタル信号出力、BNC型(×3)

コンポジット:Y、C、KEY、Z シリアルデ

ジタル信号出力、BNC型(×4)

EXTERNAL INPUT

コンポーネント:EXT シリアルデジタル信

号入力、BNC型(×1)

リモートコントロール信号

CONTROL PANEL

RS-422A信号規格準拠、D-sub 9ピン(×2)、

D-sub 25ピン(×2)

EDITOR

RS-422A信号規格準拠、D-sub 9ピン

SWITCHER PANEL

RS-422A信号規格準拠、D-sub 9ピン(×2)

AUX

RS-422A信号規格準拠、D-sub 9ピン(×2)

GPI

入力4、出力4、プログラマブル、D-sub 15

ピン

性能(アナログ信号入出力時)

直線性(コンポジット)

DG:2%以下

DP:2°以下

(40 IREのSCを重畳したRAMP信号)

周波数特性

コンポーネント

Y:500kHz~5MHz, ±0.8dB

R-Y、B-Y:500kHz~2.5MHz

±0.8dB

コンポジット:500kHz~4.2MHz、±0.5dB

パルス特性

K≤1%、2Tパルス

S/N比

コンポーネント:55dB以上

コンポジット:55dB以上

Y/Cディレイ

コンポーネント:20ns以下

コンポジット:15ns以下

サンプリング

クロック周波数

コンポーネント:13.5MHz

コンポジット:14.3MHz

量子化ビット

アナログ:10ビット

デジタル入出力:10ビット

内部処理:10~12ビット

システムディレイ

システムディレイ

1フレーム

入力位相差吸収範囲

 $-0.3H\sim+1.8H$

付属品

ラックアングル(本体に取り付け済み)

電源コード (1)

電源コード用プラグアダプター (1)

プラグホルダー (2)

D-sub 25ピンケーブル、10m (1)

75Ω終端器 (1)

インストレーションマニュアル (1)

メンテナンスマニュアル Part 1 (1)

関連製品

DME-3000用コントロールパネル BKDM-3010 デジタルビデオスイッチャー DVS-2000C デジタルビデオスイッチャー DVS-2600/2600C DVS-2000C/2600用コントロールパネル BKDS-2010 デジタルビデオスイッチャー DVS-6000/6000C DVS-6000/6000C用コントロールパネル BKDS-6010 エディティングコントロールユニット BVE-2000

別売り品

D-sub 25ピン30mケーブル SWC-2530D オペレーションソフトウェア ウィズ マニュアル BZDM-3010 データディスプレイユニット CPD-15SF7



1-4-2 BKDM-3010 DME CONTROL PANEL

一般

電源

DC10~15V

消費電力

12W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

-20~+60℃(保存)

外形寸法

424×84×285mm(幅×高さ×奥行き)(突起物

を除く)

重量

3.5kg

入出力端子

PROCESSOR

D-sub 25ピン、メス

MONITOR

D-sub 15ピン、メス

SPARE

D-sub 9ピン、オス

1-4-3 BKDM-3020 COMPOSITE DIGITAL INPUT/OUTPUT BOARD

一般

電源

DC5±0.2V

 $DC-5\pm0.1V$

 $DC12\pm1V$

消費電力

40W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.2kg

入出力

入力

D2シリアルデジタル信号(VIDEO A/B、KEY

A/B)

リファレンス信号(ブラックバースト)

出力

D2シリアルデジタル信号(VIDEO 1/2、KEY

1/2)

1-4-4 BKDM-3021 COMPONENT DIGITAL INPUT/OUTPUT BOARD

一般

電源

DC5±0.2V DC-5±0.1V

DC12±1V

消費電力

40W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.2kg

入出力

入力

D1シリアルデジタル信号(VIDEO A/B、KEY

A/B)

リファレンス信号(ブラックバーストまたはコ

ンポジットシンク)

出力

D1シリアルデジタル信号(VIDEO 1/2、KEY

1/2)

1-4-5 BKDM-3022 COMPOSITE DIGITAL/ANALOG INPUT/OUTPUT BOARD

一般

電源

DC5±0.2V

DC-5±0.1V

 $DC12\pm1V$

消費電力

60W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.4kg

操作 ||||||||||||

入出力

入力

D2シリアルデジタル信号(VIDEO A/B、KEY

A/B)

アナログNTSC信号(VIDEO A/B、KEY A/B)

リファレンス信号(ブラックバースト)

出力

D2シリアルデジタル信号(VIDEO 1/2、KEY

1/2)

アナログNTSC信号(VIDEO 1/2、KEY 1/2)

1-4-6 BKDM-3023 COMPONENT DIGITAL/ANALOG INPUT/OUTPUT BOARD

一般

電源

DC5±0.2V

 $DC-5\pm0.1V$

 $DC12\pm1V$

消費電力

60W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.4kg

入出力

入力

D1シリアルデジタル信号(VIDEO A/B、KEY

A/B)

アナログコンポーネント信号(Y/R-Y/B-Y

A/B、KEYA/B)

リファレンス信号(ブラックバーストまたはコ

ンポジットシンク)

出力

D1シリアルデジタル信号(VIDEO 1/2、KEY

1/2)

アナログコンポーネント信号(Y/R-Y/B-Y

1/2、KEY 1/2)

R/G/B/SYNC出力に切り換え可能

1-4-7 BKDM-3030 NON-LINEAR EFFECTS BOARD

一般

電源

 $DC5\pm0.2V$

消費電力

20W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×220.8mm (幅×高さ×奥行き) (突起

物を除く)

重量

0.5kg

その他

CPU

R3081、クロック周波数25MHz

1-4-8 BKDM-3040 WIPE/GRAPHICS BOARD

一般

電源

DC5±0.2V

消費電力

25W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.3kg

その他

CPU

R3051、クロック周波数25MHz

1-4-9 BKDM-3050 COMBINER/LIGHTING BOARD

一般

電源

 $DC5\!\pm\!0.2V$

DC-5±0.1V

消費電力

50W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.3kg



入出力

入出力

D1/D2シリアルデジタル信号(VIDEO/Y、

EXT/C, KEY/Z, Z)

1-4-10 BKDM-3060 KEY CHANNEL/RECURSIVE EFFECTS BOARD

一般

電源

DC5+0.2V

消費電力

20W

使用温度

5~40℃(動作保証)

10~35℃(性能保証)

外形寸法

317×20×380mm(幅×高さ×奥行き)(突起物

を除く)

重量

1.2kg

メモリー容量

キーチャンネルブロック

1フレーム

リカーシブブロック

1フレーム×2

仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

第2章 設 置

2-1. 使用環境


- ・セット内の温度上昇を防止するために、設置する 場所の空気の循環には充分注意してください。ま た、外筐の通気孔を決して覆わないようにしてく ださい。
- セットの動作環境温度は、5℃~40℃ですので、セットを熱源のそばに設置しないでください。

2-2. 一次側電源電圧


 DME-3000の電源にはスイッチングレギュレータを 使用しており、90 V~264 Vの間は電源電圧を変 更することなく使用できます。
 ラッシュカレントは、最大25 Aです。

2-3. 外形寸法

・ セットの外形寸法は下記の通りです。








2-4. 設置スペース

1. DME-3000


DME-3000の後方は、サービス性の点から壁などより 最低20 cm離してください。





2. BKDM-3010

BKDM-3010は下記のように調卓にはめ込んで使用することができます。




2-5. トラックボールの取付け

出荷時のコントロールパネルには、トラックボールが装着されていません。

トラックボールの取り付けは以下の手順で行ってください。

- (1) ボールカバーを反時計方向に回して外す。
- (2) 図に示す位置にトラックボールを入れる。
- (3) ボールカバーを元の位置へはめ込み、時計方向に回して固定する。



DME-3000


2-6. 設置時の確認および設定

2-6-1. 基坂内スイッチの設定および LED の説明

注意:()内は、基坂上のアドレスを示しています。

1. DME-3000

CPU-114基板



A面(部品面)

・スイッチ

S1 (G-1): リセットスイッチ プロセッサをリセットします。

S2 (H-1):割り込みスイッチ

RS-232Cポートからの通信を受信するために、割り 込み処理を実行させるスイッチです。 このスイッチは押さないでください。

S301-1 (D-16): Memory Clear スイッチ

ON:電源ON時にKFデータを消去します。

OFF: KF データをバックアップします。 工場出荷時は OFF に設定されています。

S301-2 (D-16): Editor プロトコルセレクター リアパネル部のD-SUB Editorのプロトコルを選沢

します。

ON: VTRプロトコル

OFF: DMEプロトコル

(BVE-9000/9100 + BKE-9009)

工場出荷時は OFF に設定されています。

(続く)

V1.40 以降の場合:

セットアップメニュー上 (702 OPERATION) で Editor のプロトコルの設定が可能です。

	POWER ON モード		
	Factory Set	User Define	
電源投入時	スイッチ設定 が有効	メニュー設定 が有効	
セットアップ メニューで 再設定時	メニュー設定 が有効	メニュー設定 が有効	

S301-3, S301-4 (D-16):

工場出荷時はBit 3, Bit 4 ともに OFF に設定されています。

このスイッチはインストールされているオペレーティングソフトウェアのバージョンにより、機能が異なります。

V1.00 の場合: AUX プロトコルセレクター リアパネル部の D-SUB AUX のプロトコルを選 択します。

Bit 3	Bit 4	選択プロトコル
OFF	OFF	CARTプロトコル
		(DVS-V1201, BKDM-5080)
ON	OFF	SW' ERプロトコル
		(DVS-8000/6000/2000シリーズ)
ON	ON	未使用

V1.11 以降の場合: Factory Use

製造時に使用するスィッチです。

Bit 4 は必ず OFF に設定してください。

なお、AUXのプロトコルの設定はセットアップ メニュー上 (711 SOURCE SELECTOR) で可 能になっています。 S301-5 (D-16): Factory Use製造時に使用するスイッチです。必ず工場出荷時の設定(OFF)で使用してください。

S301-6 (D-16): 未使用 工場出荷時はOFFに設定されています。

S301-7, S301-8 (D-1): 物理チャンネル設定スイッチ 物理チャンネル(*)を設定します。

Bit 7	Bit 8	物理チャンネル	
OFF	OFF	CH1	
OFF	ON	CH2	
ON	OFF	СНЗ	
ON	ON	CH4	


工場出荷時はBit 7, Bit 8ともにOFFに設定されています。

(*): 物理チャンネルとは、コントロールパネルに 複数のプロセッサを識別させるために、各プ ロセッサに与える番号です。

• LED

ND301 (F-1): CPU RUNインジケータ CPUの動作状態に対応した数字が表示されます。

MPU-70基板



A面 (部品面)

・スイッチ

S3 (J-4): エミュレータモード設定スイッチ このスイッチは必ず工場出荷時の設定で使用して ください。

工場出荷時の設定:

-	Bit	1	2	3	4	5	6	7	8
	設定	OFF	ON						

S201 (F-1): リセットスイッチ MPU-70基板のCPUをリセットします。


• LED

D202 (G-1): FDインジケータ(緑) 毎フィールドのCPUの割り込みごとに点滅しま す。

D203 (G-1): RUNインジケータ(緑) CPUが動作しているときに点灯します。

2. BKDM-3010

CPU-119基板



S1 (L-6): リセットスイッチ コントロールパネルをリセットします。

S2 (E-8): テストスイッチ

工場出荷時の設定:

Bit	1	2	3	4	5	6	7	8
設定	ON	ON	ON	ON	OFF	OFF	OFF	ON

S2-1~S2-6: CN3テストスイッチ

S2-1: RX-A信号をコネクタ(CN3)に接続します。

S2-2: RX-B信号をコネクタ(CN3)に接続します。

S2-3: TX-A信号をコネクタ(CN3)に接続します。

S2-4: TX-B信号をコネクタ(CN3)に接続します。

S2-5: TX-B信号とRX-B信号を内部同志で接続します。

動作チェックをするために使用します。

S2-6: TX-A信号とRX-A信号を内部同志で接続します。

動作チェックをするために使用します。

S2-7, S2-8: CN1テストスイッチ


S2-7: TXD信号とRXD信号を内部同志で接続します。

動作チェックをするために使用します。

S2-8: RXD信号をコネクタ(CN1)に接続します。

3. BKDM-3030

MPU-72基板



・スイッチ

S901 (F-7): リセットスイッチ MPU-72基板のCPUをリセットします。

S902 (G-7): システムデバック用スイッチ

このスイッチを押すとシステムデバックモードに入り、D903~D910がプログラムのバージョン表示を行います。

システムデバックモードから抜けるためには、 CPU-114基板のリセットスイッチ(S1)を押してくだ さい。

通常はこのスイッチを押さないでください。

• LED

D901 (D-7): RUNインジケータ(緑) CPUが動作しているときに点灯します。

D902 (D-7): VDインジケータ(緑)

VD信号の有無を示します。VD信号が正常に基板に 入力されているときに点灯します。

注意: D901, D902ともに点灯していないと、MPU-72 基板は正常に動作しません。

D903~D910 (E-7): STATUSインジケータ MPU-72基板の動作状態を8 bitのHEXコードで表示します。

1/


: LEDが点灯

(データの意味は"1"を表わします。)

: LEDが消灯


(データの意味は"0"を表わします。)

STATUS CODE	動作状態
エフェクト番号 / \ MSB LSB	MPU-72基板が正常動作状態であることを示します。 下位5 bitはコントロールパネルで選択されたエフェクト番号を表示します。 下位5 bitが全て"0"のときはノンリニアエフェクトがOFF状態です。
MSB LSB	MPU-72基板が初期設定状態であることを示します。 初期設定終了後は、自動的に正常動作状態に移行します。
MSB LSB	MPU-72基板がシステムデバック状態であることを示します。 このとき、一定周期でブートプログラムとエフェクトプログラムのバージョンが下位4 bitに表示されます。 1の位 バージョンの1の位を表示 MSB LSB 10の位 バージョンの 10の位を表示 MSB LSB 1100の位 バージョンの 100の位を表示
(続く)	MSB LSB



4. BKDM-3040

WKG-13基板



・スイッチ

S1 (N-1): リセットスイッチ WKG-13基板のCPUをリセットします。

S2 (P-1): システムデバック用スイッチ このスイッチを押すとシステムデバックモードに 入り、D102~D109がプログラムのバージョン表示 を行います。 システムデバックモードから抜けるためには、

CPU-114基板のリセットスイッチ(S1)を押してくだ

通常はこのスイッチを押さないでください。

• LED

D100 (E-1): CPU RUNインジケータ(緑) CPUが動作しているときに点灯します。

D101 (E-1): GDC RUNインジケータ(縁) Graphic Display Controllerが動作しているとき に点灯します。

注意: D100, D101ともに点灯していないと、WKG-13 基板は正常に動作しません。

D102~D109 (E-1): STATUSインジケータ


WKG-13基板の動作状態を8 bitのHEXコードで表示します。

: LEDが点灯

(データの意味は"1"を表わします。)

: LEDが消灯

(データの意味は"0"を表わします。)





STATUS CODE	動作状態
(続き)	(例) ブートプログラムバージョン V1.30 アプリケーションプログラムバージョン V1.50
	MSB LSB システムデバック状態表示
	N
	時間
	表示 OFF バージョン表示
	Application Ver 1.50
	システムデバック状態表示
\ \ \ \ \ \ \ \ \ \ \ \ \	WKG-13基板が動作不良状態であることを示します。 この場合は基板を交換する必要があります。

2-6-2. カード基板の設置方法

DME-3000は、各基板ごとに設置すべきスロットが定められています。下記にしたがって各基板が所定のスロットに正しく設置されているか確認してください。


Slot No.	標準基板	オプション基板
1	CPU-114	無し
2	空きスロット	
3	MPU-70	MPU-72 (BKDM-3030)
4		WKG-13 (BKDM-3040)
5		CMB-1 (BKDM-3050)
6	空きスロット	
7		KPC-2 (BKDM-3060)
8	DPR-35	無し
9		VIF-6 VIF-9 (BKDM-3022)
		VIF-6A VIF-9A (BKDM-3021) (BKDM-3020) 4つのうちいずれか1つ

注意: MPU-70基板とMPU-72基板の接続方法については2-6-3項「オプション基板の取付け」を参照してください。

- ・ 基板の左端カードプラグ付近には、A面に基板名称 とその基板を設置できるスロット番号が表示され ています。
- ・ DME-3000は、オプション基板の選択により、様々なシステムへの対応や機能の拡張が可能です。各オプション基板も本体基板と同様、左端カードプラグ付近にあるスロットNo.の表示にしたがって、定められた範囲および順序で設置してください。

注意

- 1. 各基板のコネクタがゆるみなく本体のMB-438基板 に接続しているか確認してください。
- 2. 設置のスロットをまちがえると、システムエラーとなり、正しく作動しません。
- 3. オプション基板を追加したり、基板の交換を行った場合は、必ず電源電圧を再確認してください。



2-6-3. オプション基板の取付け


DME-3000には、下記のようなオプション基板があります。

- · BKDM-3020 (VIF-9A基板)
- · BKDM-3021 (VIF-6A基板)
- · BKDM-3022 (VIF-9基板)
- · BKDM-3023 (VIF-6基板)
- · BKDM-3030 (MPU-72基板)
- · BKDM-3040 (WKG-13基板)
- · BKDM-3050 (CMB-1基板)
- · BKDM-3060 (KPC-2基板)


ここでは、BKDM-3030(MPU-72基板)の取付けについて記載します。その他のオプション基板の取付けについては、Maintenance Manual Part.1の1-7章「基板の取付け/取外し」を参照してください。

〈BKDM-3030(MPU-72基板)の取付け方法〉 以下の手順でMPU-72基板をMPU-70基板に接続してく ださい。

(1) ダミープレートを止めているネジ7本を外す。



- (2) MPU-72基板のコネクタをMPU-70基板のコネク タに接続する。
- (3) MPU-72基板を手順 (1) で外したネジ7本でMPU-70基板およびシールド板ASSYに取り付ける。



2-6-4. 二次側電源電圧の確認

DME-3000には+5 V(A), +5 V(B), -5 V, +12 V の電源があります。


POWERインジケータは+5 V(A), ファンは+12 Vを使用しています。

設置後、下記にしたがってセット内部の電源電圧を確 認してください。

1. 十5 V(A), 十5 V(B), -5 Vの電圧測定

各基板には+5 V(A), +5 V(B), -5 Vの電圧測定の ためにデジタル電圧計のプローブを差し込めるチェッ クターミナルが用意されています。下記の手順で電圧 を確認してください。

- (1) フロントパネルを開き、電源ユニットが正しく挿 入され、4本のネジで固定されていることを確認 する。
- (2) 電源をONし、CPU-114基板のCPU RUNインジケータ(ND301)が、点灯していることを確認する。




- (3) 基板抜け止めASSYを止めているネジ(BVTT 3×5)5本を外す。
- (4) 各基板上のチェックターミナル間にデジタル電圧 計を接続し、各チェックターミナルの電圧値が下 表の規格を満たしていることを確認する。

電圧	規格	チェックターミナル	調整ボリューム
+5 V(A)	$+5.00 \pm 0.05 \text{ V}$	CPU-114基板 CN302(+5 V) ⇔ CN303(GND)	RV1
+5 V(B)	$+5.00 \pm 0.05 \text{ V}$	VIF-*基板 CN1(+5 V) ⇔ CN3(GND)	RV2
-5 V	$-5.00 \pm 0.05 \text{ V}$	VIF-*基板 CN2(-5 V) ⇔ CN3(GND)	RV3

VIF-*基板: VIF-6/9/6A/9A基板

- 規格外であれば、下記にしたがって電圧調整を 行ってください。
 - デジタル電圧計は上記ターミナルに接続したまま 調整を行います。
 - i) 電源ユニットの目かくし板を外す。
 - ii) 調整窓から調整ドライバを差し込み、該当する スイッチングレギュレータの電圧調整ボリュー ムを回す。デジタル電圧計を見ながら、適正な 電圧が得られるまで、調整する。
- 注意1: 基板抜け止めASSYを取り外さずに、デジタル電圧計を接続しないでください。チェックターミナルと基板抜け止めASSYの間でショートする危険があります。
- 注意2: 電源電圧の設定は、使用する全てのカード基 板を挿入した状態で行ってください。




2. 十12 Vの電圧測定

+12 Vは電圧の調整は必要ありませんが、電圧を確認する必要がある場合は、下記の手順で電圧を確認してください。

- (1) Maintenance Manual Part 1の1-4-2項「ファン の交換」を参照して、ファンカバーを取り外す。
- (2) D Cファン用のコネクタ端子(CN301または CN302)の1 PIN(+12 V)と3 PIN(GND)間にデジタル電圧計を接続し、電圧値が規格を満たしていることを確認する。

規格: +12 + 1 V



2-6-5. マルチチャンネル時の設定

一台のコントロールパネルから複数のDME-3000をコントロールするためには、コントロールパネルが各々のDME-3000を別々のチャンネルNo.で認識する必要があります。これを物理(フィジカル)チャンネルと呼びます。

フィジカルチャンネルの設定は、DME-3000のCPU-114基板上のS301スイッチのbit 7, bit 8の設定により 行います。

フィジカルチャンネル	bit 7	bit 8
1	OFF	OFF
2	OFF	ON
3	ON	OFF
4	ON	ON

このとき、複数のDME-3000に対して各々異なるフィジカルチャンネルを設定してください。

フィジカルチャンネルとコントロールパネルに表示される論理(ロジカル)チャンネルNo.とは必ずしも同一のものではありません。セットアップメニューでフィジカルチャンネルとロジカルチャンネルの対応を決めることができます。


(セットアップメニューの詳細については、BZDM-3010/3020のUser's Guideの「チャンネル番号の割り 付け-701」(10-4ページ)を参照してください。)

注意: チャンネル番号の割り付けが行われていない場合は、メニュー画面上に "Communication Error"と表示され、コントロールパネルとプロセッサの通信に障害があることを知らせます。


2-6-6. コンバイナー基板設置時の設定

オプションのコンバイナー基板(BKDM-3050·CMB-1 基板)を設置し、コンバイナー機能を使って複数画像の 合成を行う場合は、コンバイナー入出力コネクタの接 続を行う必要があります。

下記にしたがってコネクタを接続してください。



(※2): DME 1とDME 2の合成画像をDME 2から 得ることに限定した場合は、これらの接 続は不要となります。



DME-3000

2-7. 接続コネクタ

設置・サービス時などにおいて、リアパネル上のコネクタにケーブルを接続する際には、下記のコネクタまたはその同等品を接続してください。

1. DME-3000

	· · · · · · · · · · · · · · · · · · ·
リアパネル部の	接続するケーブル側の
コネクタの機能名称	コネクタの部品番号および名称
DIGITAL INPUTS	
DIGITAL OUTPUTS	·
ANALOG INPUTS	BNCコネクタ
ANALOG OUTPUTS	1-560-009-00
COMBINER INPUTS	1-300-003-00
COMBINER OUTPUTS	
REF INPUT	
	D-SUB 25 PIN (MALE)
	[1-566-356-11
CONTROL PANEL	CONNECTOR 25 P, MALE
	1-563-377-11
	JUNCTION SHELL 25 P
	D-SUB 15 PIN (MALE)
	[1-564-592-11
GPI	CONNECTOR 15 P, MALE
	1-563-376-11
	JUNCTION SHELL 15 P
CONTROL PANEL	D-SUB 9 PIN (MALE)
EDITOR	[1-560-651-00
AUX	CONNECTOR 9 P, MALE
SWITCHER PANEL	1-561-749-00
SWITCHER TAKEL	JUNCTION SHELL 9 P

2. BKDM-3010

リアパネル部の	接続するケーブル側の
コネクタの機能名称	コネクタの部品番号および名称
	D-SUB 25 PIN (MALE)
	[1-566-356-11
PROCESSOR	CONNECTOR 25 P, MALE
	1-563-377-11
	JUNCTION SHELL 25 P
MONITOR	CPD-1431に付属
CDADD	PCY-330またはマイクロソ
SPARE	フト(*)マウスに付属

(*): Microsoftは米国マイクロソフト社の登録商標です。


2-8. コネクタの入出力信号

2-8-1. DME-3000

DIGITAL INPUTS ANALOG INPUTS COMBINER INPUTS **REF INPUT** DIGITAL OUTPUTS ANALOG OUTPUTS COMBINER OUTPUTS


-BNCコネクタ, 75 Ω終端

CONTROL PANEL: RS-422 (D-SUB 9 PIN)



信号名	機能		
FG	フレームグランド		
CIONZ A	コントロールパネルへの送信		
1 XA-	データ(一)		
DXD	コントロールパネルからの受		
KXB+	信データ(十)		
GND	グランド		
NC	未接続		
GND	グランド		
CVD	コントロールパネルへの送信		
IXBT	データ(十)		
DVA	コントロールパネルからの受		
KAA-	信データ(一)		
FG	フレームグランド		
	FG TXA- RXB+ GND NC GND TXB+ RXA-		

CONTROL PANEL: RS-422 (D-SUB 25 PIN)




(FEMALE)

-EAI	A 117 AA	


PIN No.	信号名	機能
1	FG	フレームグランド
2	POWER	コントロールパネル用電源 (+12 V)
3	TXA-	コントロールパネルへの送信 データ(一)
4	GND	グランド
5	RXA-	コントロールパネルからの受 信データ(一)
6	NC	
7	NC	未接続
8	NC	
9	VDA-	コントロールパネルへの垂直 ドライブ信号(一)
10	NC	土拉结
11	NC	√ 未接続
12	GND	グランド
13	GND	10776
14	POWER	コントロールパネル用電源 (+12 V)
15	POWER	コントロールパネル用電源 (+12 V)
16	TXB+	コントロールパネルへの送信 データ(+)
17	GND	グランド
18	RXB+	コントロールパネルからの受 信データ(+)
19	NC	
20	NC	未接続
21	NC	
22	VDB+	コントロールパネルへの垂直 ドライブ信号(+)
23	NC	未接続
24	NC	小 对外机
25	FG	フレームグランド

EDITOR: RS-422 (D-SUB 9 PIN)




PIN No.	信号名	機能
1	FG	フレームグランド
2	TXA-	エディターへの送信データ (一)
3	RXB+	エディターからの受信データ (+)
4	GND	グランド
5	NC	未接続
6	GND	グランド
7	тхв+	エディターへの送信データ (+)
8	RXA-	エディターからの受信データ (一)
9	FG	フレームグランド

AUX: RS-422 (D-SUB 9 PIN)




PIN No.	信号名	機能
1	FG	フレームグランド
2	RXA-	マトリックススイッチャー などからの受信データ(一)
3	тхв+	マトリックススイッチャー などへの送信データ(+)
4	GND	グランド
5	NC	未接続
6	GND	グランド
7	RXB+	マトリックススイッチャー などからの受信データ(+)
8	TXA-	マトリックススイッチャー などへの送信データ(一)
9	FG	フレームグランド

SWITCHER PANEL: RS-422 (D-SUB 9 PIN)




PIN No.	信号名	機能
1	FG	フレームグランド
2	TXA-	スイッチャーパネルへの送信 データ(一)
3	RXB+	スイッチャーパネルからの受 信データ(+)
4	GND	グランド
5	NC	未接続
6	GND	グランド
7	TXB+	スイッチャーパネルへの送信 データ(+)
8	RXA-	スイッチャーパネルからの受 信データ(一)
9	FG	フレームグランド

GPI: D-SUB 15 PIN



PIN No.	信号名	PIN No.	信号名
1	FG	9	GPIO1G
2	GPIO1	10	GPIO2G
3	GPIO2	11	GPIO3G
4	GPIO3	12	GPIO4G
5	GPIO4	13	GPIIG
6	GPII1	14	GPII2
7	GPII3	15	GPII4
8	GPIIG		


PROCESSOR: RS-422 (D-SUB 25 PIN)



-EXT VIEW-


PIN No.	信号名	機能		
1	GND	グランド		
2	POWER	+12 V 入力		
3	RX-A	プロセッサーからの受信デー タ(一)		
4	GND	グランド		
5	TX-A	プロセッサーへの送信データ (一)		
6	NC			
7	NC	未接続		
8	NC ·			
9	VD-A	垂直ドライブ信号入力(一)		
10	GND	グランド		
11	NC	未接続		
12	GND	グランド		
13	GND	9721		
14	POWER	- +12 V 入力		
15	POWER			
16	RX-B	プロセッサーからの受信デー タ(+)		
17	GND	グランド		
18	TX-B	プロセッサーへの送信データ (+)		
19	NC			
20	NC	未接続		
21	NC			
22	VD-B	垂直ドライブ信号入力(十)		
23	NC			
24	NC			
25	GND	グランド		

SPARE: RS-232C (D-SUB 9 PIN)



PIN No.	信号名	機能
1	NC	未接続
2	TXD	送信データ
3	RXD	受信データ
4	DTR	データ端末レディ
5	GND	グランド
6	NC	未接続
7	RTS	送信要求
8	NC	- 未接続
9	NC	>1-13-13-1

MONITOR: RGB出力 (D-SUB 15 PIN·3 LINES)



PIN No.	信号名	機能
	D	R出力
1	R	0.714 V p-p(\pm 10%)/75 Ω
0	C	G出力
2	G	$0.714 \text{ V p-p}(\pm 10\%)/75 \Omega$
3	В	B出力
3	Ь	$0.714 \text{ V p-p}(\pm 10\%)/75 \Omega$
4	GND	グランド
5	NC	未接続
6	GND	
7	GND	グランド
8	GND	
9	NC	未接続
10	GND	グランド
11	GND	
12	NC	未接続
13	H sync	H sync 出力 (TTL level)
14	V sync	V sync 出力 (TTL level)
15	NC	未接続

2-9. 付属アクセサリ

1. DME-3000

品 名	部品番号	個数
電源コード	1-551-812-11	1
ACプラグ変換アダプタ3P-2P	1-506-411-21	1
プラグホルダ (UC用)	2-990-242-01	1
プラグホルダ(EK用)	3-170-078-01	1
75 Ω終端器	1-695-542-11	1
D-SUB 25ピンケーブル(10 m)	1-696-660-11	1
ネジ(BVTT4×8)	7-685-881-04	8
デジタルビデオ用ケーブル(10 m)	1-765-378-51	1
インストレーションマニュアル		1
メンテナンスマニュアル Part.1		1

2. BKDM-3010

品 名	部品番号	個数
インストレーション		1
アンドメンテナンスガイド	_	
トラックボール (*)	4-930-625-01	1

(*):トラックボールは別梱包品のため、出荷時は本 体に装着されていません。

2-9-1. 付属電源コードの接続


(J,UC) 使用部品

① AC プラグ変換アダプタ 3P-2P

1-506-411-21 (月用)

- ② 電源コード
- 1-551-812-11
- ③ プラグホルダ (黒)

2-990-242-01



(EK) 使用部品

プラグホルダ (灰色) 3-170-078-01

2-10. 別売アクセサリ

DME-3000 およびBKDM-3010の別売アクセサリとして、下記のものが用意されています。

- · 延長基板 (ソニー部品番号: J-6188-100-A)
- 電源調整ケーブル (DC-SVC)(ソニー部品番号: J-6189-590-A)
- ・ D-SUB 25 ピン30 m ケーブル (SWC-2530D)
- ・ ラックマウントレール (RMM-30)
- CRT モニタ (CPD-sf7 など)
- ・ マウス (PCY-330 など)
- · BKDM-3020: DIGITAL COMPOSITE INPUT/ OUTPUT BOARD
- · BKDM-3021: DIGITAL COMPONENT INPUT/ OUTPUT BOARD
- BKDM-3022: DIGITAL/ANALOG COMPOSITE INPUT/OUTPUT BOARD
- BKDM-3023 : DIGITAL/ANALOG COMPONENT INPUT/OUTPUT BOARD
- · BKDM-3030: NON-LINEAR EFFECTS BOARD
- · BKDM-3040: WIPE & GRAPHICS BOARD
- · BKDM-3050: COMBINER & LIGHTING BOARD
- BKDM-3060: KEY CHANNEL & RECURSIVE EFFECTS BOARD
- BZDM-3010: OPERATION SOFTWARE WITH MANUAL (JAPANESE)
- BZDM-3020: OPERATION SOFTWARE WITH MANUAL (ENGLISH)

2-11. ラックマウント

DME-3000は、19インチ標準ラックに組み込んで使用することができます。このときレールは、オプションのラックマウントレールRMM-30を必ず使用してください。

〈用意するもの〉

・ ラックマウントレール (RMM-30)

ブラケット付きレール :2個 ネジ (B5×8) :8本 ・ネジ (BVTT4×8)* :6本

・ ラックマウント用ネジ (RK5×16):4本

・ ラックマウント用飾りワッシャ :4個

(ソニー部品番号: 2-297-913-01)


*: DME-3000 に付属

〈取付け時の注意〉


- (1) 19インチ標準ラックにDME-3000および関連機種をラックマウントしたときは、ラック内の温度上昇を防止するため、換気用ファンを取り付けることをお薦めします。ラック内の全てのセットが5℃~40℃の範囲で使用できるように注意してください。
- (2) ラックマウントするときは、必ず推奨のレールを ご使用ください。ラックアングルだけでは、セッ トをラックに固定できないため、危険です。
- (3) ラックはしっかりした床にボルトで固定すること をお薦めします。セットをラックから引き出す際 に、倒れかかってくるのを防止します。
- (4) ラックマウントレール RMM-30には、設置マニュアルが同梱されていますが、DME-3000で使用する場合は、一部 RMM-30のマニュアル記載内容と異なるため、本マニュアルの手順に従ってください。

〈取付け方法〉


(1) ラックマウントレールRMM-30のストッパを押し ながら、インナーメンバを引き抜く。




(2) DME-3000に付属しているネジ(BVTT 4×8)6本 を使って、インナーメンバをセットに取り付け る。また、セットに付いている脚は、必要に応じて外す。



(3) アウターメンバに止めてある後部ブラケットのネジをゆるめ、前後方向のブラケットの位置を調整する。




(4) RMM-30に付属しているネジ(B5×8)8本を使って、前部ブラケットおよび後部ブラケットをラック取り付け位置の外側へ仮止めする。







(5) 収納するときは、インナーメンバのストッパを押しながら、アウターメンバに差し込み最後まで押し込む。



- (6) スムーズに収納できることを確認した後、手順 (4)で仮止めしたネジ(B5×8)を締め付ける。
- 注意: 前部ブラケットをラックにネジ止めするとき は、セットをラックから20 cm程度手前に引き 出すこと。
- (7) ラックに収納した後、用意したネジ(RK5×16)4本 と飾りワッシャ4個を使って、セットをラックに 固定する。



・ DME-3000をラックマウントしたときの最大移動距 離は、下図の通りです。




2-12. ソフトウェアのインストール方法

DME-3000およびBKDM-3010のCPUプログラムは、フロッピーディスクから電気的に消去可能なフラッシュメモリにインストールします。よって、バージョンアップの際にはROMの交換は不要となります。 工場出荷時にはすでにCPUプログラムが記憶されていますが、古いバージョンの場合がありますので、必ず下記の手順に従ってソフトウェアのインストールを行ってください。

〈予備知識〉

GLBL, CH1, CH2, 10 BKGD EDGE, F8, EXIT の6つのキーを同時押しすることにより、コントロールパネルのリセットが可能です。



2-12-1. BKDM-3010

1. ソフトウェアのインストール方法

下記の手順でコントロールパネルのソフトウェアをインストールしてください。

- (1) SYSTEM DISK 1(ソフトウェア)をディスクドライブに挿入する。
- (2) 電源をONする。または、コントロールパネルを リセットする。
- (3) 画面上に以下の表示がされたら F2 (store flash) キーを押す。

F1 F2 F3 F4 F5 boot store directory directory boot floppy flash flash

- (4) インストールが終了すると、画面上に「store flash rom complete」と表示される。
- (5) フロッピーディスクを入れたままの状態で F5 (boot flash)キーを押すと、フラッシュメモリからプログラムがロードされ、コントロールパネルが立ち上がる。

 フラッシュメモリによるコントロールパネルの 立上げ方法

下記の手順でフラッシュメモリからプログラムをロードし、コントロールパネルを立ち上げてください。

- (1) ディスクドライブからフロッピーディスクを抜い ておく。
- (2) 電源を ON する。または、コントロールパネルを リセットする。
- (3) フラッシュメモリからプログラムがロードされ、 コントロールパネルが立ち上がる。
- 3. フロッピーディスクによるコントロールパネルの 立上げ方法

フラッシュメモリ上のプログラムを使わずに、直接フロッピーディスク上のプログラムからコントロールパネルを立ち上げるには、下記の手順に従ってください。

- (1) SYSTEM DISK 1 (ソフトウエア) をディスクド ライブに挿入する。
- (2) 電源を ON する。または、コントロールパネルを リセットする。
- (3) 画面上に以下の表示がきれたら F1 (boot floppy) キーを押す。

F1 F2 F3 F4 F5 boot store directory directory boot floppy flash floppy flash flash

(4) フロッピーディスクからプログラムがロードされ、コントロールパネルが立ち上がる。

2-12-2. DME-3000

1. ソフトウェアのインストール方法

下記の手順でプロセッサのソフトウェアをインストールしてください。

- (1) SYSTEM DISK 2 (ソフトウェア) をディスクド ライブに挿入する。
- (2) SETUP & DIAG メニューの 3 段目で F4 (IN-STALL) を選択する。または、テンキーで 724 頁 目を選択する。
- (3) チャンネル1にインストールする場合はCHI キーを押し、チャンネル2にインストールする場合はCH2 キーを押す。 チャンネルを選択した後、FI (INSTALL) キーを押す。
- (4) インストールを実行する場合は F5 (OK) キーを押し、実行をやめる場合は F6 (CANCEL) キーを押す。

注意:インストールを実行している間は、他の操作を行うことができません。

(5) インストールが終了すると、約10秒後に画面上に「Finished」と表示される。

詳細については、BZDM-3010/3020のUser's Guide を参照してください。

2-13. システム接続時のスイッチ設定

システム接続時には、以下の接続例にしたがって DME-3000と接続する相手側機器のスイッチの設定を 行ってください。


なお、DME-3000のスイッチの設定については、2-6-1 項「基板内スイッチの設定およびLEDの説明」を参照してください。

また、ユニットアドレス(UA2)を設定するときは、下記のUA2設定表(表1)にしたがって相手側機器の基板内UA2設定スイッチを設定してください。

UA2設定表(表1)

UA2	スイッチ設定
01	Bit 1 ON(他はOFF)
02	Bit 2 ON(他はOFF)
04	Bit 3 ON(他はOFF)
08	Bit 4 ON(他はOFF)
10	Bit 5 ON(他はOFF)
20	Bit 6 ON(他はOFF)
40	Bit 7 ON(他はOFF)
80	Bit 8 ON(他はOFF)

2-13-1. デジタルビデオスイッチャーとの接続




※ デジタルビデオスイッチャー(DVS-2600, DVS-6000/6000C, DVS-8000/8000C)と接続する際には、各スイッチャーのUser's Guide(「セットアップ」の章)を参照してセットアップの設定を行ってください。

参照マニュアル

- ・BZS-2610 User's Guide: セットアップ SETUPボタン-スイッチャーのセットアップ (周辺機器に関する設定)
- ・BZS-6010 User's Guide: 第11章 セットアップ 《SETUP》メニュー設定項目一覧表 (4: PERIPH)
- ・BKDS-8010 User's Guide: 第9章 セットアップ オンエアタリーの設定 — ON AIR TALLY メニュー

2-13-2. BKDM-5080との接続




<BKDM-5080>

CPU-99基板

- ・S3: UA2設定 UA2設定表(表1)にしたがってユニットアドレス (UA2)を設定してください。
- S8: CART+プロトコル設定S8-1とS8-2は必ずOFF(CART+プロトコル)に設定してください。
- ※ BKDM-5080のスイッチ設定の詳細については、 BKDM-5080のMaintenance Manual 1-7章を参照 してください。





<DVS-V1201/BVS-V1201>

IF-278 基板

· S2:UA2 設定

DME-3000と接続される各機器を上図に示されるユニットアドレス (UA2) に設定してください。 それぞれのユニットアドレスのスイッチ設定については、UA2 設定表 (表1) を参照してください。

アナログコンポーネント時の接続上の注意

アナログコンポーネントビデオ信号を切り換える場合は、BVS-V1201を3台用意してください。 同一ユニットアドレスに設定されている3台に対し、 IF-278 基板上のスイッチ S1-8 (REMOTE 1, 2の RESPONSE) を、1台のみOFFに設定し、他の2台をONに設定してください。 ※ DVS-V1201/BVS-V1201のスイッチ設定の詳細については、DVS-V1201またはBVS-V1201の各Maintenance Manual 1-4章を参照してください。

About the DME-3000 Digital Multi Effects Manuals

The following manuals are necessary in order to operate the DME-3000 Digital Multi Effects and control it from the BKDM-3010 Control Panel.

DME-3000 Installation Manual

(This manual, supplied with the DME-3000.) Chapter 1 "OPERATION" provides an overview of the DME-3000, describes connectors and optional boards, and shows how the unit can be incorporated in video processing systems. Persons who will be

responsible for system maintenance should first read this chapter. The second and following chapters contain information needed to install the system.

DME-3000 Maintenance Manual Part 1

(Supplied with the DME-3000.)

Provides information needed for maintenance. Read this manual when you need to perform system maintenance or when trouble is suspected.

DME-3000 Maintenance Manual Part 2

(Optional)

Describes information regarding system hardware.

BZDM-3020 User's Guide

(Supplied with the optional software.)

Describes the BKDM-3010 Control Panel and explains how to use it to operate this unit. Persons who will operate the DME-3000 should read this manual.

•

SECTION 1 OPERATION

1-1 Overview

Featuring all-digital processing, the DME-3000 is a video multieffects unit which can process the input from digital video switchers and similar equipment to achieve a variety of sophisticated effects with no loss in picture quality.

The DME-3000 is operated from the optional BKDM-3010 Control Panel.

1-1-1 Principal Features

Serial digital I/O

All digital signals are input and output via serial interfaces, making it possible to transfer digital video signals over a single cable with BNC connectors. This permits easier connections than conventional parallel interfaces, as well as longer transfer distances.

10-bit processing

Both analog and digital signals are input and output as 10-bit signals, with internal processing carried out using 10 to 12 bits of precision, for minimal degradation in picture quality.

Compatible with component and composite signals

Four optional I/O boards (BKDM-3020/3021/3022/3033) allow a choice of all digital or combined digital/analog I/O for both component and composite systems. You can adapt the DME-3000 to existing systems simply by choosing the appropriate I/O board for the connected video switcher. For component systems, a menu operation makes it easy to switch between 525/625 formats.

Compatible with 16:9 component signals

The DME-3000 system, including optional I/O boards, is compatible with 13.5 MHz 16:9 wide-screen component signals as well as with 4:3 component signals. A simple menu operation makes it easy to switch between 4:3 and 16:9 signals.



Integration with DVS-series digital video switchers

The following functions are available when a DVS-series video switcher is connected.

- DVS-2000C: DME WIPE®
- DVS-6000/6000C: KEY FRAME LINK®
- DVS-8000/8000C: KEY FRAME LINK[®], DME-3000 control Digital connections between the DME-3000 and DVS-series switchers permit integrated video processing with no loss in picture quality. Note, however, that some restrictions apply when controlling the DME-3000 from the BKDS-8010 Control Panel for the DVS-8000/8000C.

Simultaneous, multichannel operation

When an additional DME-3000 is connected to this unit, you can control both DME-3000 units as two channels from the same control panel, either simultaneously or one channel at a time. Simultaneous, multichannel operation is also possible when connecting the DME-5000 Digital Multi Effects.

Image combination using a combiner function

By installing optional BKDM-3050 boards in two DME-3000 units, and connecting the two units serially, you can combine two images on the same screen. This function uses special signals containing depth information, allowing you to rotate combined images around global axes for sophisticated 3-D effects. Combination functions are also available when connecting the DME-5000.

Automatic switching between frame and field processing

Depending on the amount of motion in the picture, the DME-3000 processes images in units of frames or fields. Frame processing utilizes all of the information contained in two fields, for minimal degradation in picture quality. Frame processing is suitable for creating a new image using effects as it ensures high precision. Field processing yields more natural and flowing movement when pictures contain rapid motion. The unit uses an internal motion detector to switch between the two modes automatically.

1-1-2 Optional accessories

BKDM-3010 DME Control Panel

Control panel for the DME-3000.

BKDM-3020 Composite Digital Input/Output Board

For input and output of D2 serial digital signals.

BKDM-3021 Component Digital Input/Output Board

For input and output of D1 serial digital signals.

BKDM-3022 Composite Digital/Analog Input/Output Board

For input and output of D2 serial digital signals and analog NTSC signals.

BKDM-3023 Component Digital/Analog Input/Output Board

For input and output of D1 serial digital signals and analog component signals.

BKDM-3030 Non-Linear Effects Board

For generation of non-linear effects with the DME-3000.

BKDM-3040 Wipe/Graphics Board

Allows the DME-3000 to generate wipe crop, modify mask, and color mix effects, and enables display of picture frames and rotation axes for 3-D transforms.

BKDM-3050 Combiner/Lighting Board

Adds depth information, allowing the combination of images from two DME-3000 units and the addition of lighting effects to the image output from the DME-3000.

BKDM-3060 Key Channel/Recursive Effects Board


Allows the DME-3000 to handle external keys and add recursive effects to key and video signals.

BZDM-3020 Operation Software with Manual

Software for operation of the DME-3000 and BKDM-3010, and an operation manual for the control panel.

1-1-3 Peripherals Configuration

The configuration of peripheral equipment around the DME-3000 is as follows. The dotted lines enclose components needed for the minimum system configuration.



Peripherals configuration

1-1-4 Functions provided by option boards

The table below shows the functions made available when option boards are installed in the basic system. The "basic system" in the table means the configuration shown within the dotted lines in the illustration on the previous page.

Meaning of ○ and ● symbols

- O: Functions in lines with the O symbol are available when the option board for that column is installed.
- ●: Functions in lines with the symbol are available when two or more option boards are installed. For example, the "page turn using external key signal" function is available when the BKDM-3030, BKDM-3050 and BKDM-3060 boards are installed.

Functions provided by option boards

	Basic system (DME-3000 + BKDM-3010+ BKDM-302X)		Option	boards	
Digital multi-effects functions		BKDM-3030	BKDM-3040	BKDM-3050	BKDM-3060
10-bit 4:2:2:4 signal processing	0				0
External kev					
Interpolation in units of frames	0				
3-D linear transform	0		ļ		
Video modify	0				
Input freeze	0		 		
Border, crop	0		 	<u> </u>	+
Multi-move	0				-
Non-linear effects		0	 	 	
Split/mirror		0	 		-
Drop shadow (3-D linear)	0				
Drop shadow (non-overlap non-linear)		0	 		
Drop shadow (overlap non-linear¹))		•	 		
Video defocus, blur	0			 	0
Key defocus, blur				 	0
Recursive effects				-	
Dim/fade				 	
Combine				-	
Improved overlap non-linear edge quality		•		+	
Page turn using external key signal		•		0	
Lighting (bar, flat)				+	
Lighting (bar, flat, circle)		-	0	 	
Spot lighting by wipe pattern			+	-	1
Wipe crop, modify mask				-	
Color mix			-	+	•
Graphics					

Overlap non-linear refers to a non-linear effect in which an input video image overlaps a copy of itself in the process of transformation. The sphere, cylinder, page turn and roll effects of the DME-3000 are overlap non-linear effects. All other non-linear effects are non-overlap non-linear effects.

1-1-5 Option board precautions

Handling option boards

Normally it should not be necessary to remove or replace boards. When you do have to install boards or remove them for maintenance purposes, observe the following precautions.

- Before inserting or removing a board, always turn the unit off. For the location of the POWER switch, see page 1-7 (E).
- After inserting a new board, and before turning on the power, make sure that the number on the board matches the number on the slot.


Note

Failure to observe these precautions may result in damage to the internal circuits.




1-2 Location and Function of Parts


1-2-1 Front Panel and Interior



Front panel



Opening the front panel



Interior of front panel

Slot numbers correspond to option boards as follows.


Slot numbers and option boards

Slot	Supplied as	Option boards			
number standard		Board name	Model name		
1	CPU-114				
2					
3	MPU-70	MPU-72 Non-Linear Effects Board	BKDM-3030		
4		WKG-13 Wipe/Graphics Board	BKDM-3040		
5		CMB-1 Combiner/Lighting Board	BKDM-3050		
6			-		
7 .		KPC-2 Key Channel/Recursive Effects Board	BKDM-3060		
8	DPR-35				
		VIF-9A Composite Digital I/O Board	BKDM-3020		
9		VIF-6A Component Digital I/O Board	BKDM-3021		
		VIF-9 Composite Digital/Analog I/O Board	BKDM-3022		
		VIF-6 Component Digital/Analog I/O Board	BKDM-3023		

Notes

- Insert the appropriate I/O board for your system in slot 9. By inserting one of the four available I/O boards you can switch between component and composite modes.
- When using a component mode, make the appropriate settings for the "525/625" and "4:3/16:9" switches in the BKDM-3010 SYSTEM menu.

The CPU-114 board and BKDM-3020 to BKDM-3023 I/O boards have indicators to show the operating status of the system, and controls for testing and adjustment purposes. They are located on the front of the boards (near the front side of the cabinet).



Switches, indicators and connectors on internal boards

1 +5 V (A) check connectors

For insertion of probe to check +5 V (A) voltage.

2 CPU RUN indicator

A numerical indication of the operational state of the CPU appears.

3 RESET switch

Resets the CPU.

4 Interrupt switch

When set to ON, executes interrupt processing for reception of data through the RS-232C port. Normally do not touch this switch.

6 RS-232C port

Communications port. Normally do not connect anything to this port.


6 Maintenance connector

Reserved for maintenance purposes. Normally do not connect anything.

7 +5 V (B), -5 V check connectors

For insertion of probe to check +5 V (B) and -5 V voltage.

1-2-2 Rear Panel



Rear panel

1 COMBINER INPUTS connectors (BNC type)

When combining the image on this unit with the image from another DME-3000, input special purpose serial digital signals for combiner operation. The combined image is output from the DIGITAL OUTPUTS connectors • and ANALOG OUTPUTS connectors •. Use the VIDEO/Y, KEY/Z and Z connectors for component format, and the VIDEO/Y, EXT/C, KEY/Z and Z connectors for composite format. When using the component format, serial digital signals input through the EXT/C connector can be used as background or borders. The BKDM-3050 option board must be installed in this unit in order to use these connectors.

2 COMBINER OUTPUTS connectors (BNC type)

When combining the image on this unit with the image from another DME-3000, output special purpose serial digital video signals for combiner operation. Use the VIDEO/Y, KEY/Z and Z connectors for component format, and the VIDEO/Y, EXT/C, KEY/Z and Z connectors for composite format. The BKDM-3050 option board must be installed in this unit in order to use these connectors.

3 ANALOG INPUTS connectors (BNC type)

Input analog video signals and key signals. If the phase difference between these signals and the reference video signals input through the REF INPUT connector **6** is within –0.3 H to +1.8 H, automatic phase adjustment is carried out. However, in order to enable automatic phase adjustment, it is necessary to choose one of the four possible values under TBC CENTER (TBC window center position) in the IN/OUT menu of the BKDM-3010 Control Panel. The BKDM-3022 or BKDM-3023 option board must be installed in this unit in order to use these connectors.

4 DIGITAL OUTPUTS connectors (BNC type) Output serial digital video signals and key signals. The same signals are output from two connectors, OUTPUT 1 and OUTPUT 2. In order to use these

OUTPUT 1 and OUTPUT 2. In order to use these connectors, one of the BKDM-3020, BKDM-3021, BKDM-3022, or BKDM-3023 option boards must be installed in this unit.

6 ANALOG OUTPUTS connectors (BNC type)

Output analog video signals and key signals. The same signals are output from two connectors, OUTPUT 1 and OUTPUT 2. The BKDM-3022 or BKDM-3023 option board must be installed in this unit in order to use these connectors.

6 REF (reference video) INPUT connectors (BNC type)

Input analog reference video signals. The two connectors form a loop-through connection. Signals input into either connector can be output unchanged from the other. When not using the loop-through connection, always terminate the unused connector with the supplied 75 Ω terminator.

7 SPARE connectors (BNC type)

These connectors are reserved for future use.

8 DIGITAL INPUTS connectors (BNC type) Input serial digital video signals and key signals. If the phase difference between these signals and the reference video signals input through the REF INPUT connector 6 is within –0.3 H to +1.8 H, automatic phase adjustment is carried out. However, in order to enable automatic phase adjustment, it is necessary to choose one of the four possible values under TBC CENTER (TBC window center position) in the IN/OUT menu of the BKDM-3010 Control Panel. One of the BKDM-3020, BKDM-3021, BKDM-3022, or BKDM-3023 option boards must be installed in this unit in order to use these connectors.

OCONTROL PANEL connectors (D-sub 9-pin, D-sub 25-pin)

Connect the optional BKDM-3010 Control Panel to one of the D-sub 25-pin connectors. The four connectors form a loop-through connection. Connecting the unused D-sub 25-pin connector to another DME-3000 makes it possible to control both DME-3000 units from the same control panel. These connectors comply with the RS-422A standard. They supply +12 V power and reference video signals to the BKDM-3010. The D-sub 9-pin connectors are reserved for future use.

10 AUX connectors (D-sub 9-pin)

Connecting an external matrix switcher to one of these connectors allows you to switch the signals input to this unit from the matrix switcher. Only one of the two connectors should be used.

11 EDITOR connector (D-sub 9-pin)

Connecting a BVE-2000 or other editing control system allows you to control this unit from the editor. This connector complies with the RS-422A standard.

@ GPI connector (D-sub 15-pin)

Connect to external equipment to input trigger signals. There are four inputs. You can set the input conditions for each connector using the BKDM-3010 Control Panel menu.

B AC IN connector

Connect to an AC outlet with the supplied power cord.

GROUND terminal


Connect the system ground.

(B) SWITCHER PANEL connectors (D-sub 9pin)

Connecting the BKDS-6010 Control Panel for the DVS-6000 Digital Video Switcher allows you to run or recall key frame effects from the switcher control panel. Connecting the BKDS-8010 Control Panel for the DVS-8000/8000C Digital Video Switcher allows you to control the DME-3000 from the switcher control panel. In this case, however, certain functions of this unit are subject to limitations.

These two connectors form a loop-through connection. Connecting a second DME-3000 unit to the unused connector allows you to control both digital multi-effects units from the same switcher control panel.

1-2-3 BKDM-3010 Control Panel (Option) Rear Panel



BKDM-3010 control panel (option) rear panel

1 PROCESSOR connector (D-sub 25-pin)

Connect to the DME-3000. Reference video signals, +12 V power and RS-422A signals are supplied by the DME-3000 through this connector.

2 MONITOR connector (D-sub 15-pin, high density)

Connect a CPD-15SF1 or other monitor.


3 RS-232C connector (D-sub 9-pin)

A MicrosoftTM Mouse¹⁾ can be connected.

¹⁾ Microsoft is a trademark of Microsoft Corporation.

1-3 System Configuration Examples


1-3-1 Control Panel and I/O Connections



Control panel and I/O connections


1-3-2 DVS-2000C Digital Video Switcher Connections

When the optional BKDM-3050 board is not installed, output key signals from the DIGITAL OUTPUTS KEY connector of the DME-3000.




DVS-2000C Digital Video Switcher connections

1-3-3 DVS-6000/6000C Digital Video Switcher Connections




DVS-6000/6000C digital video switcher connections

1-3-4 DVS-8000/8000C Digital Video Switcher and DME-5000 Digital Multi Effects Connections




DVS-8000/8000C and DME-5000 connections

1-3-5 BVE-2000 Editing Control System Connections



BVE-2000 editing control system connections

1-3-6 DVS-V1201 Digital Video Routing Switcher Connections



DVS-V1201 digital video routing switcher connections

1-4 Specifications

1-4-1 DME-3000 Digital Multi Effects

General

Power requirement

90 to 264 V AC

Power consumption

Approx. 400 W (with all optional boards

installed)

Supply power factor 90% or above

Operation

temperature

-20°C to 55°C (-4°F to 131°F) (storage) 5°C to 40°C (41°F to 104°F) (operation

guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed)

Relative humidity

80% or less (operation guaranteed)

70% or less (performance guaranteed)

Dimensions

 $424 \times 221.2 \times 450 \text{ mm} (16 3/4 \times 8 3/4 \times$

17 3/4 inches) (w/h/d) (excluding

projections)

Mass

25 kg (55 lb 1 oz) (with all optional boards

installed)

input/output connectors

DIGITAL INPUTS

VIDEO: Serial digital signal input,

BNC (\times 2), 75 Ω

KEY: Serial digital signal input,

BNC (\times 2), 75 Ω

Composite

VIDEO: Serial digital signal input,

BNC (\times 2), 75 Ω

KEY: Serial digital signal input,

BNC (\times 2), 75 Ω

DIGITAL

OUTPUTS

Component

VIDEO: Serial digital signal output,

BNC (\times 2), 75 Ω

KEY: Serial digital signal output,

BNC (\times 2), 75 Ω

Composite

VIDEO: Serial digital signal output,

BNC (\times 2), 75 Ω

KEY: Serial digital signal output,

BNC (\times 2), 75 Ω

ANALOG INPUTS	Component
	Y, R-Y, B-Y: Analog component signal
	input, BNC (×6)
	Y: 1 Vp-p, with sync signal
	R-Y, B-Y: 0.7 Vp-p
	KEY: VS, 1 Vp-p, BNC (×2)
1	Composite
•	VIDEO: Analog composite signal input,
	BNC (×2)
	KEY: VS, 1 Vp-p, BNC (×2)
ANALOG	Component
OUTPUTS	Y, R-Y, B-Y (when outputting color
0011015	difference signal): Analog component
	signal output, BNC (×6)
	Y: 1 Vp-p, with sync signal
	R-Y, B-Y: 0.7 Vp-p
	R, G, B, SYNC (when outputting RGB
	signal): Analog RGB signal output,
	BNC (×8)
	R, G, B: 0.7 Vp-p
	SYNC: 2.35 Vp-p
	KEY: VS, 1 Vp-p, BNC (×2)
	Composite
	VIDEO: Analog composite signal output,
	BNC (×2)
	KEY: VS, 1 Vp-p, BNC (×2)
REF INPUT	Component
	Analog reference signal input, BNC (×2),
	black burst or composite sync,
	0.3 to 2 Vp-p, loop-through
	Composite
	Analog reference signal input, BNC (×2),
	black burst, loop-through
COMBINER	Component: VIDEO, KEY, Z Serial digital
INPUTS	signal input, BNC (×3)
	Composite: Y, C, KEY, Z Serial digital
	signal input, BNC (×4)
COMBINER	Component: VIDEO, KEY, Z Serial digital
OUTPUTS	signal output, BNC (×3)
	Composite: Y, C, KEY, Z Serial digital
	signal output, BNC (×4)
EXTERNAL INPUT	Component: EXT Serial digital signal input,
	BNC (×1)



Remote control signal

CONTROL PANEL Complies with RS-422A standard,

D-sub 9-pin (\times 2) and D-sub 25-pin (\times 2)

Complies with RS-422A standard, D-sub 9-pin **EDITOR**

SWITCHER PANEL Complies with RS-422A standard,

D-sub 9-pin (\times 2)

AUX Complies with RS-422A standard,

D-sub 9-pin (\times 2)

GPI 4 inputs, 4 outputs, programmable,

D-sub 15-pin

Performance (when inputting and outputting analog signals)

Linearity (composite) Differential gain: 2% maximum

Differential phase: 2° maximum (measured with a ramp signal on which 40 IRE sub-

carrier signal is superimposed)

Frequency response Component

> Y: 500 kHz to 5 MHz, ±0.8 dB R-Y, B-Y: 500 kHz to 2.5 MHz,

±0.8 dB

Composite: 500 kHz to 4.2 MHz,

 $\pm 0.5 dB$

S/N ratio

Pulse characteristics K: 1% maximum, 2T pulse

Component: 55 dB or above

Y/C delay

Composite: 55 dB or above Component: 20 ns maximum

Composite: 15 ns maximum

Sampling

Clock frequency

Component: 13.5 MHz

Composite: 14.3 MHz

Quantization

Analog: 10 bits

Digital I/O: 10 bits

Internal processing: 10 to 12 bits

System delay

System delay

1 frame

Input phase

adjustment range

-0.3H to +1.8H

Accessories

Rack mounting angles (1 set, fitted to cabinet)

Power cord (1)

Plug adaptor for power cord (1)

Plug holder (2)

D-sub 25-pin cable, 10 m (1)

75 Ω terminator (1)

Installation Manual (1)

Maintenance Manual Part 1 (1)

Related equipment

BKDM-3010 Control Panel for DME-3000 DVS-2000C Digital Video Switcher DVS-2100C Digital Video Switcher BKDS-2010 Control Panel for DVS-2000C/2100C DVS-6000/6000C Digital Video Switcher BKDS-6010 Control Panel for DVS-6000/6000C BVE-2000 Editing Control Unit

Optional Accessories

SWC-2530D D-sub 25-pin cable, 30 m BZDM-3020 Operation Software with Manual CPD-15SF1 Data Display Unit

1-4-2 BKDM-3010 DME Control Panel

General

Power requirements 10 to 15 V DC

Power consumption

Operation 5

5°C to 40°C (41°F to 104°F) (operation guaranteed)

12 W

temperature

10°C to 35°C (50°F to 95°F) (performance

guaranteed

-20°C to 60°C (-4°F to 140°F) (storage)

Dimensions

 $424 \times 84 \times 285 \text{ mm} (163/4 \times 33/8 \times 111/4)$

inches) (w/h/d) (excluding projections)

Mass

3.5 kg (7 lb 11 oz)

Input/output connectors

PROCESSOR

D-sub 25-pin, female

MONITOR

D-sub 15-pin, female

SPARE

D-sub 9-pin, male

1-4-3 BKDM-3020 Composite Digital Input/Output Board

General

Power requirements $5 \pm 0.2 \text{ V DC}$

 $-5 \pm 0.1 \text{ V DC}$

 $12 \pm 1 \text{ V DC}$

40 W

Power consumption

Operation

temperature

5°C to 40°C (41°F to 104°F) (operation

guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 \frac{1}{2} \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass

1.2 kg (2 lb 10 oz)

input/output

Input

D2 serial digital signal (VIDEO A/B, KEY

A/B)

Reference signal (black burst)

Output

D2 serial digital signal (VIDEO 1/2, KEY 1/2)

1-4-4 BKDM-3021 Component Digital Input/Output Board

General

Power requirements $5 \pm 0.2 \text{ V DC}$

 $-5 \pm 0.1 \text{ V DC}$

 $12 \pm 1 \text{ V DC}$

Power consumption 40 W

Operation

 5° C to 40° C (41° F to 104° F) (operation

temperature

guaranteed)

 10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass

1.2 kg (2 lb 10 oz)

Input/output

Input

D1 serial digital signal (VIDEO A/B, KEY

A/B)

Reference signal (black burst or composite

sync)

Output

D1 serial digital signal (VIDEO 1/2, KEY 1/2)

1-4-5 BKDM-3022 Composite Digital/Analog Input/Output Board

General

Power requirements $5 \pm 0.2 \text{ V DC}$

 $-5 \pm 0.1 \text{ V DC}$

12 ± 1 V DC

Power consumption

60 W

Operation

5°C to 40°C (41°F to 104°F) (operation

temperature

guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass 1.4 kg (3 lb 1 oz)

input/output

Input

D2 serial digital signal (VIDEO A/B, KEY

A/B)

Analog NTSC signal (VIDEO A/B, KEY A/B)

Reference signal (black burst)

Output

D2 serial digital signal (VIDEO 1/2, KEY 1/2) Analog NTSC signal (VIDEO 1/2, KEY 1/2)

BKDM-3023 Component Digital/Analog Input/Output Board

General

 $5 \pm 0.2 \text{ V DC}$ Power requirements

> $-5 \pm 0.1 \text{ V DC}$ 12 ± 1 V DC

Power consumption 60 W

5°C to 40°C (41°F to 104°F) (operation Operation

temperature guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass 1.4 kg (3 lb 1 oz)

Input/output

Input D1 serial digital signal (VIDEO A/B, KEY

Analog component signal (Y/R-Y/B-Y A/B,

KEY A/B)

Reference signal (black burst or composite

sync)

D1 serial digital signal (VIDEO 1/2, KEY 1/2) Output

> Analog component signal (Y/R-Y/B-Y 1/2, KEY 1/2), switchable to R/G/B/SYNC

output

1-4-7 BKDM-3030 Non-Linear Effects Board

General

 $5 \pm 0.2 \text{ V DC}$ Power requirements

Power consumption 20 W

5°C to 40°C (41°F to 104°F) (operation Operation

temperature guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions $317 \times 20 \times 220.8 \text{ mm} (12 1/2 \times 13/16 \times 8 3/4)$

inches) (w/h/d) (excluding projections)

Mass 0.5 kg (1 lb 1 oz)

Other

CPU R3081, clock frequency 25 MHz

1-4-8 BKDM-3040 Wipe/Graphics Board

General

 5 ± 0.2 V DC Power requirements

Power consumption

25 W

Operation

 5° C to 40° C (41° F to 104° F) (operation

temperature

guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass

1.3 kg (2 lb 13 oz)

Other

CPU

R3051, clock frequency 25 MHz

1-4-9 BKDM-3050 Combiner/Lighting Board

General

Power requirements

 $5 \pm 0.2 \text{ V DC}$ $-5 \pm 0.1 \text{ V DC}$

Power consumption

50 W

Operation

temperature

5°C to 40°C (41°F to 104°F) (operation

guaranteed)

 10°C to 35°C (50°F to 95°F) (performance

guaranteed)

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass

1.3 kg (2 lb 13 oz)

Input/output

Input/output

D1/D2 serial digital signal (VIDEO/Y,

EXT/C, KEY/Z, Z)

1-4-10 BKDM-3060 Key Channel/Recursive Effects Board

General

Power requirements $5 \pm 0.2 \text{ V DC}$

Power consumption

20 W

Operation temperature 5° C to 40° C (41° F to 104° F) (operation

guaranteed)

10°C to 35°C (50°F to 95°F) (performance

guaranteed

Dimensions

 $317 \times 20 \times 380 \text{ mm} (12 1/2 \times 13/16 \times 15)$

inches) (w/h/d) (excluding projections)

Mass

1.2 kg (2 lb 10 oz)

Memory capacity

Memory channel

1 frame

block

Recursive block

1 frame \times 2

Design and specifications are subject to change without notice.

SECTION 2 INSTALLATION

2-1. OPERATING ENVIRONMENT


- To prevent a rise in the temperature inside the unit, pay careful attention to the circulation of air in the place where the unit is installed. Never block the ventilation holes of the outer cabinet.
- The operating environmental temperature of the unit is 5 °C to 40 °C. Do not install the unit in a location near heat sources.

2-2. PRIMARY SUPPLY VOLTAGE


A switching regulator is used for the power supply of the DME-3000. The voltage within the range of 90 V to 264 V can be used without changing the supply voltage. The rush current is 25 A (maximum).

2-3. EXTERNAL DIMENSIONS

 The external dimensions of the unit are shown in the figure below.








DME-3000

2-4. INSTALLATION SPACE


1. DME-3000

For purpose of serviceability, the DME-3000 should be installed at least 20 cm away from the wall.



2. BKDM-3010

The BKDM-3010 can be installed in the control console during use as the following figure.




2-5. TRACK BALL INSTALLATION

The track ball is not installed in the control panel at the factory.

Install the track ball according to the procedure below.

- (1) Turn the ball cover counterclockwise and remove
- (2) Put a track ball in the position shown in the figure.
- (3) Put the ball cover in the former position, turn it clockwise, then fix.






2-6. CONFIRMATION AND SETTING DURING INSTALLATION

2-6-1. Switch Setting on Board and LED Description

Note: The address on the board is shown by () mark.

1. DME-3000

CPU-114 board



A Side (Component side)

Switches

S1 (G-1): Reset switch Resets the processor.

S2 (H-1): Interrupt switch

Executes the interrupt processing so as to receive the communication data from an RS-232C port. Do not press this switch.

S301-1 (D-16): Memory clear switch

ON: Erases the KF data when the power is turned

OFF: Backs up the KF data.

This switch is set to OFF at the factory.

S301-2 (D-16): Editor protocol selector

Selects the protocol of the D-SUB editor connector on the rear panel.

ON: VTR protocol

OFF: DME protocol (BVE-9000/9100 + BKE-9009)

This switch is set to OFF at the factory.

When V1.40 or more is installed:

Editor protocol can be set by the setup menu (702 OPERATION).

	POWER ON Mode			
	Factory Set	User Define		
When power is turned on	Switch setting takes effect.	Menu setting takes effect.		
When proto- col is reset by setup menu	Menu setting takes effect.	Menu setting takes effect.		

S301-3 and S301-4 (D-16):

Bit 3 and Bit 4 are set to OFF at the factory. The function of these switches depends on installed operating software's version.

When V1.00 is installed: AUX protocol selector Selects the protocol of the D-SUB AUX connector on the rear panel.

Bit 3	Bit 4	Selected Protocol	
OFF	OFF	CART protocol	
		(DVS-V1201 and BKDM-5080)	
ON	OFF	SW' ER protocol	
		(DVS-8000/6000/2000 series)	
ON	ON	Not used.	

When V1.11 or more is installed: Factory use Factory use only.

Be sure to set Bit 4 to OFF.

AUX protocol can be set by the setup menu (711 SOURCE SELECTOR).

\$301-5 (D-16): Factory use

Factory use only.

This switch is set to OFF at the factory. Be sure to use this switch for setting (OFF) at the factory.

S301-6 (D-16): Not used.

This switch is set to OFF at the factory.

S301-7 and S301-8 (D-16): Physical channel setting switch

Sets the physical channel(*).

Bits 7 and 8 are set to OFF at the factory.


Bit 7	Bit 8	Physical channel
OFF	OFF	CH1
OFF	ON	CH2
ON	OFF	СНЗ
ON	ON	CH4

(*):The physical channel is the number assigned to each processor so that the control panel can discriminate multiple processors.

· LED

ND301 (F-1): CPU RUN indicator

A numerical indication of the operational state of the CPU appears.



A Side (Component side)

Switches

S3 (J-4): Emulator mode setting switch
Be sure to use this switch for setting at the factory.
Factory setting:

Bit	1	2	3	4	5	6	7	8
Setting	OFF	ON						

S201 (F-1): Reset switch Resets the CPU on the MPU-70 board.


• LEDs

D202 (G-1): FD indicator (Green)

Blinks whenever CPU interrupt processing is executed in each field.

D203 (G-1): RUN indicator (Green)
Lights during the CPU operation.

2. BKDM-3010



S1 (L-6): Reset switch Resets the control panel.

S2 (E-8): Test switch Factory setting:

Bit	1	2	3	4	5	6	7	8
Setting	ON	ON	ON	ON	OFF	OFF	OFF	ON O

S2-1 through S2-6: CN3 test switch

S2-1: Connects a RX-A signal to connector CN3.

S2-2: Connects a RX-B signal to connector CN3.

S2-3: Connects a TX-A signal to connector CN3.

S2-4: Connects a TX-B signal to connector CN3.

S2-5: Connects TX-B and RX-B signals internally. Used for operation check.


S2-6: Connects TX-A and RX-A signals internally. Used for operation check.

S2-7 and S2-8: CN1 test switch

S2-7: Connects TXD and RXD signals internally. Used for operation check.

S2-8: Connects a RXD signal to connector CN1.

3. BKDM-3030



Switches

S901 (F-7): Reset switch

Resets the CPU on the MPU-72 board.

S902 (G-7): System debugging switch

When this switch is pressed, the board enters the system debugging mode.

Then the LEDs (D903 through D910) displays the program version number.

Press the reset switch (S1) on the CPU-114 board to exit the system debugging mode.

Do not press this switch usually.

LEDs

D901 (D-7): RUN indicator (Green) Lights during the CPU operation.

D902 (D-7): VD indicator (Green) Indicates the existence of VD signal. Lights when VD signal is normally input to the board.

Note: If either D901 or D902 lights off, the MPU-72 board does not operate normally.

D903 to D910 (E-7): STATUS indicator
Displays the operating state of the MPU-72 board
by HEX code on 8 bits.


: LED lights. (This means "1".)

11.

: LED Lights off. (This means "0".)




STATUS CODE	Operating state			
Effect number MSB LSB	Indicates that the MPU-72 board operates normally. The lower 5 bits display the effect number selected on the control panel. When the lower 5 bits are all "0", nonlinear effects are "OFF" state.			
MSB LSB	Indicates that the MPU-72 board is in initial setting. After initial setting, the board starts normal operation automatically.			
MSB LSB	Indicates that the MPU-72 board is in system debugging. Then the boot program and effect program versions are displayed in the lower 4 bits for a given period.			
	1's digit Displayed 1's digit in version number MSB LSB			
	1/10's digit Displayed 1/10's digit in version number			
	MSB LSB			
	1/100's digit Displayed 1/100's digit in version number			
(continue)	MSB LSB			



4. BKDM-3040

WKG-13 board



Switches

S1 (N-1): Reset switch Resets the CPU on the WKG-13 board.

S2 (P-1): System debugging switch
When this switch is pressed, the board enters the system debugging mode.
Then the LEDs (D102 through D109) displays the program version number.
Press the reset switch (S1) on the CPU-114 board to exit the system debugging mode.
Do not press this switch usually.

• LEDs

D100 (E-1): CPU RUN indicator (Green) Lights during the CPU operation.

D101 (E-1): GDC RUN indicator (Green)
Lights during the graphic display controller operation.

Note: If either D100 or D101 lights off, the WKG-13 board does not operate normally.




D102 to D109 (E-1): STATUS indicator
Displays the operating state of the WKG-13 board
by HEX code on 8 bits.

: LED lights. (This means "1".)

: LED Lights off. (This means "0".)

STATUS CODE	Operating state			
COLOR MIX WIPE GRAPHIC	Indicates that the WKG-13 board operates normally. The lower bit 3 indicates that COLOR MIX operates normally. The lower bit 2 indicates that WIPE operates normally. The lower bit 1 indicates that GRAPHIC operates normally.			
NSB LSB	Indicates that the WKG-13 board is in initial setting. After initial setting, the board starts normal operation automatically.			
MSB LSB	Indicates that the WKG-13 board is in system debugging. Then the boot program and application program versions are displayed in the lower 4 bits for a given period.			
	1's digit Displayed 1's digit in version number MSB LSB			
	1/10's digit Displayed 1/10's digit in version number MSB LSB			
	1/100's digit Displayed 1/100's digit in version number			
(continue)	MSB LSB			





2-6-2. Card Boards Installation

In the DME-3000, each board must be installed in the specified slot. Confirm that each board is properly installed in the specified slot as shown in the table below.


Standard board	Optional board
CPU-114	Not used
Spare	
MPU-70	MPU-72 (BKDM-3030)
	WKG-13 (BKDM-3040)
	CMB-1 (BKDM-3050)
Spare	
	KPC-2 (BKDM-3060)
DPR-35	Not used
	VIF-6 VIF-9 (BKDM-3022)
	VIF-6A VIF-9A (BKDM-3020) One of the four boards
	Spare MPU-70 Spare

Note: For connecting procedure of the MPU-70 and MPU-72 boards, refer to section 2-6-3, "Optional Board Installation".

- The board name and the slot number in which the board can be installed are displayed on A side near the card plug on the left edge of the board.
- The DME-3000 can obtain compatibility with various systems and can extend its function by the selection of an optional board. Like the standard board, each optional board should also be installed in the specified range and procedure according to the slot number display near the card plug on the left edge.

Notes:

- Confirm that the connectors on each board are securely connected to the MB-438 board of the main unit.
- If the board is installed in an incorrect slot, a system error occurs. Then the system is not activated properly.
- 3. Reconfirm the supply voltage when an optional board is added or the board is replaced.



2-6-3. Optional Board Installation

The DME-3000 has the optional boards below.

- BKDM-3020 (VIF-9A board)
- BKDM-3021 (VIF-6A board)
- BKDM-3022 (VIF-9 board)
- BKDM-3023 (VIF-6 board)
- BKDM-3030 (MPU-72 board)
- BKDM-3040 (WKG-13 board)
 BKDM-3050 (CMB-1 board)
- BKDM-3060 (KPC-2 board)


This section describes how to install the BKDM-3030 (MPU-72 board). For the installation of other optional boards, refer to section 1-7, "Installation and Removal

of Card Boards" in the Maintenance Manual Part 1.


< Installing procedure of the BKDM-3030 (MPU-72 board) >

Connect the MPU-72 board to the MPU-70 board according to the procedure below.

(1) Remove the seven screws fixing the dummy plate.



- (2) Connect the connector on the MPU-72 board to the connector on the MPU-70 board.
- (3) Install the MPU-72 board in the MPU-70 board and shielding plate assembly with the seven screws removed in step (1).



2-6-4. Secondary Supply Voltage Confirmation

The DME-3000 has a power supply of ± 5 V (A), ± 5 V (B), ± 5 V, and ± 12 V.


The POWER indicator uses +5 V (A), and the fan uses +12 V.

After installation is completed, confirm the supply voltage inside the unit as described below.

1. Voltage measurement of +5 V (A), +5 V (B), and -5 V

Check terminals in which the probe of a digital voltmeter can be inserted for the voltage measurement of ± 5 V (A), ± 5 V (B), and ± 5 V are provided on each board. Confirm each voltage according to the procedure below.

- (1) Open the front panel and confirm that the power unit is properly inserted and securely fixed with four screws.
- (2) Turn on the power and confirm that the CPU RUN indicator (ND301) on the CPU-114 board lights.




- (3) Remove the five screws (BVTT 3×5) fixing the board clamper ass'y.
- (4) Connect the digital voltmeter between the check terminals on each board and confirm that the voltage values of each check terminal satisfy the specification shown in the table below.

Voltage	Specifications	Check terminal	Adjustment potentiometer
		CPU-114 board RV1	
+5 V (A)	+5.00 ± 0.05 V	CN302 (+5 V) ⇔ CN303 (GND)	114 1
		VIF-*board	RV2
+5 V (B)	+5.00 ± 0.05 V	CN1 (+5 V) ⇔ CN3 (GND)	1142
	5 00 ± 0.05 V	VIF-*board	RV3
-5 V $-5.00 \pm 0.05 \text{ V}$		CN2 (-5 V) ⇔ CN3 (GND)	1140

VIF-* board: VIF-6, VIF-9, VIF-6A, or VIF-9A board

- If the above specification is not satisfied, adjust the voltage as described below.
 The voltage adjustment is performed with the digital voltmeter connected to the above check terminal.
 - i) Remove the blind plate of the power unit.
 - ii) Insert the tip of an adjustment driver from the adjustment window and turn the voltage adjustment potentiometer of the corresponding switching regulator. Adjust the potentiometer until the digital voltmeter reads a proper voltage.
- Note 1: Never connect the digital voltmeter without removing the board clamper ass'y. There is danger of causing a short circuit between the check terminals and the board clamper ass'y.
- Note 2: Set the supply voltage with all the card boards to be used inserted.






2. Voltage measurement of +12 V

A voltage of +12 V requires no adjustment. If it is necessary to confirm the voltage, confirm the voltage according to the procedure below.

- (1) Remove the fan cover referring to section 1-4-2, "Fan Replacement" in the Maintenance Manual Part 1.
- (2) Connect a digital voltmeter between 1 pin (+12 V) and 3 pin (GND) of the connector terminal (CN301 or CN302) for a DC fan and confirm that the voltage value is satisfied. Specification: +12 ± 0 V



2-6-5. Multi Channel Setting

To control multiple DME-3000s from one control panel, each DME-3000 must be recognized on the control panel by respective channel numbers. This is called a physical channel.

The physical channel is set by bits 7 and 8 of switch S301 on the CPU-114 board of the DME-3000.

Physical channel	Bit 7	Bit 8
1	OFF	OFF
2	OFF	ON
3	ON	OFF
4	ON	ON


At that time, set their different physical channels to multiple DME-3000s.


The physical channel is not necessarily same as the channel number (logical channel number) displayed on the control panel. The physical channel and its corresponding logical channel can be assigned by the setup menu.

(For details of the setup menu, refer to page 10-4 "Channel Number Assignments-701" in the User's Guide of BZDM-3010 and BZDM-3020.)

Note: When the channel number is not assigned, a message "Communication Error" appears on the menu display. This message shows that there is obstruction in communication between control panel and processor.

Each combiner input/output connectors should be connected when optional combiner boards (BKDM-3050 • CMB-1 board) are installed and when multiple pictures are synthesized using a combiner function. Connect each connector as shown below.







2-7. CONNECTORS

Connect the connector below or the equivalent when a cable is connected to the connector on the rear panel during installation and maintenance.

1.DME-3000

Function name of	Part No. and description to
connector on rear panel	be connected
DIGITAL INPUTS	
DIGITAL OUTPUTS	·
ANALOG INPUTS	BNC connector
ANALOG OUTPUTS	1-560-009-00
COMBINER INPUTS	1-300-003-00
COMBINER OUTPUTS	
REF INPUT	
	D-SUB 25 PIN(MALE)
	[1-566-356-11
CONTROL PANEL	CONNECTOR 25 P, MALE
	1-563-377-11
	JUNCTION SHELL 25 PJ
	D-SUB 15 PIN(MALE)
	1-564-592-11
GPI	CONNECTOR 15 P, MALE
	1-563-376-11
	JUNCTION SHELL 15 P
CONTROL PANEL	D-SUB 9 PIN(MALE)
EDITOR	1-560-651-00
AUX	CONNECTOR 9 P, MALE
CWITCHED DANEL	1-561-749-00
SWITCHER PANEL	JUNCTION SHELL 9 P

2.BKDM-3010

Function name of	Part No. and description to
connector on rear panel	be connected
	D-SUB 25 PIN(MALE)
	1-566-356-11
PROCESSOR	CONNECTOR 25 P, MALE
	1-563-377-11
	JUNCTION SHELL 25 P
MONITOR	Supplied for the CPD-1431.
ODADE	Supplied for the PCY-330
SPARE	or Microsoft ^(*) mouse.

(*): Microsoft is registered trademark of U.S. Microsoft corporation.


2-8. CONNECTOR INPUT/OUTPUT SIGNALS

2-8-1. DME-3000

DIGITAL INPUTS
ANALOG INPUTS
COMBINER INPUTS
REF INPUT
DIGITAL OUTPUTS
ANALOG OUTPUTS
COMBINER OUTPUTS


BNC connector, 75-ohm termination

CONTROL PANEL: RS-422 (D-SUB 9-PIN)




PIN No.	Signal name	Description	
1	FG	Frame ground	
	TVA	Data (-) transmitted to	
2	TXA-	control panel	
_		Data (+) received from	
3	RXB+	control panel	
4	GND	Ground	
5	NC	NC No connection	
6	GND	Ground	
	TVD	Data (+) transmitted to	
7	TXB+	control panel	
	RXA-	Data (-) received from	
8	HAA-	control panel	
9	FG	Frame ground	

CONTROL PANEL: RS-422 (D-SUB 25-PIN)




PIN No.	Signal name	Description	
1	FG	Frame ground	
		Power supply (+12 V) for	
2	POWER	control panel	
_		Data (-) transmitted to	
3	TXA-	control panel	
4	GND	Ground	
-	RXA-	Data (-) received from	
5	n.x.	control panel	
6	NC		
7	NC	No connection	
8	NC		
9	VDA-	Vertical drive signal (—) to	
9	VDA	control panel	
10	NC	No connection	
11	NC	NO COMMECTION	
12	GND	Ground	
13	GND	Ground	
14	POWER	Power supply (+12 V) for	
<u> </u>	1 011211	control panel	
15	POWER	Power supply (+12 V) for	
		control panel	
16	тхв⊹	Data (+) transmitted to	
	,	control panel	
17	GND	Ground	
18	RXB+	Data (十) received from	
		control panel	
19	NC		
20	NC	No connection	
21	NC		
22	VDB+	Vertical drive signal (+) to	
		control panel	
23	NC	No connection	
24	NC		
25	FG	Frame ground	

EDITOR: RS-422 (D-SUB 9-PIN)




PIN No.	Signal name	Description
1	FG	Frame ground
2	TXA-	Data (-) transmitted to editor
3	RXB+	Data (+) received from editor
4	GND	Ground
5	NC	No connection
6	GND	Ground
7	TXB+	Data (+) transmitted to editor
8	RXA-	Data (-) received from editor
9	FG	Frame ground

SWITCHER PANEL: RS-422 (D-SUB 9-PIN)




PIN No.	Signal name	Description	
11	FG	Frame ground	
2	TXA-	Data (-) transmitted to switcher panel	
3	RXB+	Data (+) received from switcher panel	
4	GND	Ground	
5	NC	No connection	
6	GND	Ground	
7	тхв+	Data (+) transmitted to switcher panel	
8	RXA-	Data (-) received from switcher panel	
9	FG	Frame ground	

AUX: RS-422 (D-SUB 9-PIN)



PIN No.	Signal name	Description
1	FG	Frame ground
2	RXA-	Data (—) received from matrix switcher
3	тхв+	Data (十) transmitted to
	.,,,	matrix switcher
4	GND	Ground
5	NC	No connection
6	GND	Ground
7	RXB+	Data (十) received from
	NAD 1	matrix switcher
8	TXA-	Data (-) transmitted to
ľ	100	matrix switcher
9	FG	Frame ground


GPI: D-SUB 15-PIN



PIN No.	Signal name	DIN No	Signal name
FIN NO.	Signal Hame	FIN NO.	Signal Haille
1	FG	9	GPIO1G
2	GPIO1	10	GPIO2G
3	GPIO2	11	GPIO3G
4	GPIO3	12	GPIO4G
- 5	GPIO4	13	GPIIG
6	GPII1	14	GPII2
7	GPII3	15	GPII4
8	GPIIG		

2-8-2. BKDM-3010


PROCESSOR: RS-422 (D-SUB 25-PIN)



-EXT VIEW-


PIN No.	Signal name	Description	
	GND		
1		Ground	
2	POWER	+12 V input	
3	RX-A	Data (-) received from	
	TOCK.	processor	
4	GND	Ground	
	TVA	Data (-) transmitted to	
5	TX-A	processor	
6	NC		
7	NC	No connection	
8	NC		
9	VD-A	Vertical drive signal input (-)	
10	GND	Ground	
11	NC	No connection	
12	GND	Ground	
13	GND	Ground	
14	POWER	140 V input	
15	POWER	+12 V input	
	DV D	Data (+) received from	
16	RX-B	processor	
17	GND	Ground	
		Data (+) transmitted to	
18	TX-B	processor	
19	NC		
20	NC	No connection	
21	NC		
22	VD-B	Vertical drive signal input (+)	
23	NC	No connection	
24	NC	No connection	
25	GND	Ground	
f			

SPARE: RS-232C (D-SUB 9-PIN)



PIN No.	Signal name	Description
1	NC	No connection
2	TXD	Transmit data
3	RXD	Receive data
4	DTR	Data terminal ready
5	GND	Ground
6	NC	No connection
7	RTS	Request to send
8	NC	No connection
9	NC	140 Comiscion

MONITOR: RGB output (D-SUB 15-PIN • 3 LINES)



PIN No.	Signal name	Description	
1	R	R output	
	' '	0.714 V p-p (\pm 10%)/75 Ω	
2	G	G output	
	<u> </u>	0.714 V p-p (\pm 10%)/75 Ω	
3	В	B output	
3	Б	0.714 V p-p (\pm 10%)/75 Ω	
4	GND	Ground	
5	NC	No connection	
6	GND		
7	GND	Ground	
8	GND		
9	NC	No connection	
10	GND	Ground	
11	GND	No connection	
12	NC	H sync output (TTL level)	
13	H sync	V sync output (TTL level)	
14	V sync	No connection	
15	NC		

2-9. SUPPLIED ACCESSORIES

1. DME-3000

Name	Part No.	Quantity
Power cord	1-551-812-11	1
AC plug 3P-2P adaptor	1-506-411-21	1
Plug holder (for UC)	2-990-242-01	1
Plug holder (for EK)	3-170-078-01	· 1
75-ohm terminator	1-695-542-11	1
D-SUB 25-pin cable (10 m)	1-696-660-11	1
Screw (BVTT 4×8)	7-685-881-04	8
Digital video cable (10 m)	1-765-378-51	1
Installation Manual	and the same of th	1
Maintenance Manual, Part.1		1

2. BKDM-3010

Name	Part No.	Quantity
Installation and Maintenance Guide	-	1
Track ball(*)	4-930-625-01	1

(*): The track ball is not installed in the main unit at the factory because it is packed separately.

2-9-1. Connection of Supplied Power Cord

Required parts (for J and UC)


1 Adaptor, AC plug 3P - 2P

1-506-411-21 (for J)

2 Power cord

1-551-812-11

③ Plug holder (black) 2-990-242-01



Required part (for EK)

Plug holder (gray) 3-170-078-01

2-10. OPTIONAL ACCESSORIES

The optional accessories of the DME-3000 and BKDM-3010 are as follows:

- Extension board (Sony part No.: J-6188-100-A)
- Power adjustment cable (DC-SVC) (Sony part No.: J-6189-590-A)
- D-SUB 25-pin cable (30 m) (SWC-2530D)
- Rack mount rail (RMM-30)
- CRT monitor (CPD-sf1)
- BKDM-3020: Digital composite input/output board
- BKDM-3021: Digital component input/output board
- BKDM-3022: Digital/analog composite input/output board
- BKDM-3023: Digital/analog component input/output board
- BKDM-3030: Non-linear effects board
- BKDM-3040: Wipe & graphics board
- BKDM-3050: Combiner & lighting board
- BKDM-3060: Key channel & recursive effects board
- BZDM-3010: Operation software with manual (Japanese)
- BZDM-3020: Operation software with manual (English)
- Mouse : Microsoft * mouse 9-pin (recommendation)
- *: Microsoft is registered trademark of U.S. Microsoft corporation.

2-11. RACK MOUNTING

DME-3000 can be mounted in a standard 19 inch rack. Be sure to use the optional rack mount rail RMM-30.

<Required Parts>

- Rack mount rail (RMM-30)
 Rails with bracket : 2 pcs
 Screws (B 5 × 8) : 8 pcs
 Screws (BVTT 4 × 6)* : 6 pcs
- Screws for rack mounting (RK 5 × 16): 4 pcs
- Ornamental washers for rack mounting: 4 pcs (Sony part number: 2-297-913-01)
- *: Supplied to DME-3000


<Cautions>

- (1) If the DME-3000 or a peripheral equipment is mounted in a 19 inch standard rack, it is recommended to install a ventilation fan to prevent a temperature bring-up in the rack. Make sure that all the units in the rack can be operated within the temperature range of 5 °C to 40 °C.
- (2) Be sure to use the recommended rail when rack mounting. The unit cannot be installed completely to a rack by rack angles alone.
- (3) It is recommended to fix the rack to the floor with bolts. When the unit is pulled out from the rack, this will prevent its fall.
- (4) An installation manual is packaged into the rack mount rail RMM-30. However follow the instructions in this manual. Because the rack mounting procedure of DME-3000 differs somewhat from the procedure explained in RMM-30 installation manual.




<Mounting Procedure>


(1) Pull out the inner member while pressing the stopper of the rack mount rail RMM-30.




(2) Attach the inner members to the unit using six screws (BVTT 4×8) supplied with RMM-30. Remove the feet of the unit as required.




(3) Loosen the screws fastening the rear bracket to the outer member. Adjust the position of the rear bracket in line with the rack depth.



(4) Attach the front and rear brackets to the outside of the rack temporarily, using eight screws (B5 \times 8) supplied with RMM-30.




(5) Install the unit in the rack. Slide the inner members fully into the outer members while pressing the stoppers of the inner members.




(6) After making sure that the unit can be installed smoothly, tighten the screws (B5×8) secured temporarily in step (4).

Note: Pull out the unit about 20 cm ($7\frac{7}{8}$ inches), and fasten the screws of the front brackets to the rack.

(7) After installing the unit in the rack, secure the unit to the rack using four screws (RK5×16) and four ornamental washers.



 When DME-3000 is mounted in a rack, the maximum travelling distance is illustrated below.






2-12. SOFTWARE INSTALLATION

The CPU programs of the DME-3000 and BKDM-3010 are installed in flash memory that can be electrically erased from a floppy disk. Therefore, ROM replacement is not required during updating.

A CPU program has already been memorized at the factory. However, the memorized CPU program may be old in a version level. Be sure to install the software according to the procedure below.

<Primarily information>

The control panel can be reset when the GLBL, CH1, CH2, 10 BKGD EDGE, F8, and EXIT keys are pressed simultaneously.




2-12-1. BKDM-3010

1. Software installation

Install the software of the control panel in the procedure below.

- Insert SYSTEM DISK 1 (software) into the disk drive.
- (2) Turn on the power or reset the control panel.
- (3) The display below appears on the screen. Then, press the F2 (store flash) key.



- (4) After installation is completed, message "store flash rom complete" is displayed on the screen.
- (5) Press the F5 (boot flash) key with the floppy disk inserted. Then a program is loaded from the flash memory and the control panel is started.

2. Starting procedure of the control panel by flash memory

Load a program from the flash memory and start the control panel in the procedure below.

- (1) Pull out a floppy disk from the disk drive.
- (2) Turn on the power or reset the control panel.
- (3) A program is loaded from the flash memory and the control panel is started.

3. Starting procedure of the control panel by floppy disk

Start the control panel by loading a program from the floppy disk without loading a program from the flash memory in the procedure below.

- (1) Insert a SYSTEM DISK 1 (software) into the disk drive.
- (2) Turn on the power or reset the control panel.
- (3) The display below appears on the screen. Then, press the F1 (boot floppy) key.

F1 boot floppy	F2 store flash	F3 directory floppy	F4 directory flash	F5 boot flash
				1

(4) A program is loaded from the floppy disk and the control panel is started.

2-12-2. DME-3000

1. Software installation

Install the software of a processor in the procedure below.

- (1) Insert SYSTEM DISK 2 (software) into the disk drive.
- (2) Select F4 (INSTALL) in step 3 of a SETUP & DIAG menu or select item 724 using a numeric keypad.
- (3) Press the CH1 key to install the software in channel 1 or press the CH2 key to install it in channel 2. Select the desired channel, then press the F1 (INSTALL) key.
- (4) Press the F5 (OK) key to execute the installation.

 If the installation is stopped, press the F6 (CANCEL) key.

Note: Another operation cannot be executed while the software is being installed.

(5) When installation is completed, message "Finished" is displayed on the screen after about ten seconds.

For details, refer to the User's Guide of the BZDM-3010 and BZDM-3020.



2-13. SWITCH SETTING DURING CONNECTING OTHER UNIT


When this unit is used in connection with other units, set the switches of other units connecting to the DME-3000 in example of system connection below. For the switch setting of the DME-3000, refer to section 2-6-1, "Switch Setting on Board and LED Description".

When setting the unit address (UA2), set the UA2 setting switch on the board of other units according to the UA2 setting table (Table 1) below.

UA2 setting table (Table 1)

-	
UA2	Switch setting
01	Bit 1 ON (Others OFF)
02	Bit 2 ON (Others OFF)
04	Bit 3 ON (Others OFF)
08	Bit 4 ON (Others OFF)
10	Bit 5 ON (Others OFF)
20	Bit 6 ON (Others OFF)
40	Bit 7 ON (Others OFF)
80	Bit 8 ON (Others OFF)

2-13-1. Connection for Digital Video Switcher




When connecting digital video switcher (DVS-2100C, DVS-6000/6000C, DVS-8000/8000C) to the DME-3000, set up the unit according to User's Guide (Chapter "Setup Operations") of each switcher.

References

- DVS-2100C User's Guide:
 Chapter 8 Setup Operations
 SETUP Menu Settings (Periph Setup menu)
- BZS-6020 User's Guide:
 Chapter 11 Setup Operations
 SETUP Menu Settings (4: PERIPH)
- BKDS-8010 User's Guide:
 Chapter 9 Setup Operations
 Making the On-Air Tally Settings ON AIR
 TALLY Menu

2-13-2. Connection for BKDM-5080




<BKDM-5080>

CPU-99 board

- S3: UA2 setting
 Set the unit address (UA2) according to the UA2
 setting table (Table 1).
- S8: CART+ protocol setting
 Be sure to set S8-1 and S8-2 to OFF (CART+
 protocol).
- For details of the switch settings of the BKDM-5080, refer to section 1-7 in the BKDM-5080 Maintenance Manual.

2-13-3. Connection for DVS-V1201/BVS-V1201



<DVS-V1201/BVS-V1201>

IF-278 board

· S2: UA2 setting

Set the unit address (UA2) of each unit connecting to the DME-3000 in the figure above.

For the switch setting of each unit address, refer to the UA2 setting table (Table 1).

Note on connection in analog component mode

When switching analog component video signal, have three BVS-V1201s ready.

Make sure that three BVS-V1201s are set to the same unit address.

In one of three BVS-V1201s, set the switch S1-8 (RESPONSE of REMOTE 1 and 2) on the IF-278 board to OFF. In two other BVS-V1201s, set the switch S1-8 on the IF-278 board to ON.

For details of the switch settings of the DVS-V1201/BVS-V1201, refer to section 1-4 in each Maintenance Manual of DVS-V1201 and/or BVS-V1201.



このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。 従って、当社の許可なしに無断で複写したり、説明内容 (操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind. Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.